

## Simple Test

Connect Cables Between DRCU simulator and DPU simulator

Power On Both Computers


Password On Both Computers are: faxel (User: Administrator)

If some hardware message would appear on the DPU simulator press ctrl +d to close it. → OK


A. Start the version DRU simulator version 3.4 or 3.5 by double clicking on the icon Transmit3.5 or Transmit3.4

B. Start the receiver on DPU simulator computer by double clicking on Receiver.exe


Your computer should now look like this



DRCU simulator side




DPU simulator side



Transmitter after number "1" has been send on channel 0-2 and received properly on transmitter side

## Enter the settings



**Repeat the same procedure as before on the receiver side**

Request editor 2 + Send

Request editor 1 + Send

Request editor 0 + Send

**After a command is send on a slow channel the receiver should start counting blocks received  
Correct transmission is indicated by a number (green if correct otherwise red)**

**If you uncheck the Loop boxes on the transmission side the transfer stops**

**For a more detailed description read then user manual section in DRU Simulator document. The command examples refers to simulator version 3.4**

?????

**H-G Florén**

**+46-8-5537 8522**  
**floren@astro.su.se**