

Enabling/Disabling of RTSI
 File: C_GSP_MCS_RTISI.xls
 Author: F. Keck



Procedure Summary

Objectives

To enabled and disable the RTSI of the MCS.

Summary of Constraints

n/a

Spacecraft Configuration

Start of Procedure

Type Pre-condition Here

End of Procedure

Type Post-condition Here

Reference File(s)

Input Command Sequences

Output Command Sequences

Referenced Displays

ANDs GRDs SLDs


Configuration Control Information

DATE	FOP ISSUE	VERSION	MODIFICATION DESCRIPTION	AUTHOR	SPR REF
06/05/08		1	Created	F. Keck	
03/08/08	1	2		F. Keck	

Enabling/Disabling of RTSI
File: C_GSP_MCS_RTSI.xls
Author: F. Keck



Procedure Flowchart Overview



Enabling/Disabling of RTSI
 File: C_GSP_MCS_RTSI.xls
 Author: F. Keck



Step No.	Time	Activity/Remarks	TC/TLM	Display/ Branch
Beginning of Procedure				
<i>SSID :</i>				
1		Enable RTSI?		Next Step: False 2 True 3
2		Disable RTSI		Next Step: END
		Open TM Spacon Choose Tab "General" Disable RTSI		
3		Enable RTSI		Next Step: END
		Open TM Spacon Choose Tab "General" Enable RTSI		
End of Procedure				