
HERSCHEL

SPIRE On-Board Software User Manual

Document Ref.: SPIRE-IFS-PRJ-001391

Issue: 1.1

Prepared by: Sergio Molinari
Scigè John, Liu

Distribution List:

RAL	K. King
	B. Swinyard
	S. "Duke" Sidher
IFSI	R. Cerulli
	R. Orfei

1	INTRODUCTION	3
1.1	PURPOSE OF THE DOCUMENT	3
1.2	ACRONYMS AND GLOSSARY	3
1.3	DOCUMENT LIST	4
1.3.1	<i>Applicable Documents</i>	4
1.3.2	<i>Reference Documents</i>	4
2	OBS COMPILATION	5
2.1	EXTERNAL COMPONENTS	5
2.2	THE VIRTUOSO PROJECT FILE	5
2.3	THE ARCHITECTURE FILE	7
2.4	COMPILING THE OBS	8
2.5	THE COMPILATION PRODUCTS	8
3	OBS LOADING ON THE DPU	9
3.1	RUNNING THE EEPROM-RESIDENT OBS	9
3.2	LOADING THE OBS VIA TELECOMMANDS	10
4	RUNTIME INSTRUCTIONS	11
4.1	TELECOMMAND VERIFICATION	11
4.2	HOUSEKEEPING DATA REPORTING	11
4.2.1	<i>Situation at Start-Up</i>	11
4.2.2	<i>Modifying the HK Packet Properties</i>	12
4.2.2.1	Sampling Interval	12
4.2.2.2	HK Packet Contents	12
4.3	MEMORY MANAGEMENT	14
4.3.1	<i>Absolute Addressing</i>	15
4.3.2	<i>Table Management</i>	15
4.3.2.1	Table Load	15
4.3.2.2	Table Update	15
4.3.2.3	Table Delete	15
4.3.3	<i>Table Defragmentation</i>	15
4.4	VIRTUAL MACHINE PROGRAMS	16
5	EVENT REPORTING	17
6	TC VERIFICATION ERROR CODES	24
7	OBS OBJECTS	28
7.1	MEMORY POOLS	28
8	VIRTUOSO OBJECTS	29
8.1	MEMORY POOLS	29
8.2	OBS TASKS	29
8.3	FIFOS	30
9	DPU MEMORY MAP	31

1 Introduction

1.1 Purpose of the document

This document describes in detail the procedures to start-up and run the SPIRE OBS, the contents of the TC packets to be uplinked in order to perform the required function, and the contents of the TM packets that the OBS generates. This document does not duplicate the information provided in RD2, but rather represents its complement for all that is not therein specified.

1.2 Acronyms and Glossary

AVM	Avionic Model
BC	Bus Controller
BP	BreakPoint
BSW	DPU Boot Software
CDMS	Command and Data Management System
DM	Data Memory (DSP)
DPU	Digital Processing Unit
DSP	Digital Signal Processor
DTST	Dedicated Test Software Tools
EGSE	Electrical Ground Support Equipment
EEPROM	Electrically Erasable Programmable Read-Only Memory
ESA	European Space Agency
HERSCHEL	Herschel Space Observatory
HK	Housekeeping
HW	Hardware
ICE	DSP In-Circuit Emulator
I/F	Interface
IFSI	Istituto di Fisica dello Spazio Interplanetario
NA	Not Applicable
OBS	On-Board Software
PM	Program Memory (DSP)
PROM	Programmable Read-Only Memory
RAM	Random Access Memory
S/C	Spacecraft
S/S	Subsystem
SUT	Software Under Test
TBC	To Be Confirmed
TBD	To Be Defined
TBW	To Be Written
TC	Telecommand
TM	Telemetry
VME	Virtual Machine Executable Code

1.3 Document List

1.3.1 Applicable Documents

Document Reference	Name	Number/version/date
AD1	SPIRE OBS User Requirements Document	SPIRE-IFS-PRJ-000444
AD2	SPIRE OBS Software Specifications Document	SPIRE-IFS-DOC-001352
AD3	Packet Structure Interface Control Document (PSICD)	SCI-PT-ICD-7527 Issue 2.0
AD4	Herschel/Planck Instrument Data Rates	H-P-1-ASPI-TN-0204 Issue: 1

1.3.2 Reference Documents

Document Reference	Name	Number/version
RD1	DPU/ICU Spacecraft Interface Test Plan	
RD2	SPIRE Data ICD	SPIRE-RAL-PRJ-001078
RD3	DRCU/DPU ICD	SPIRE-SAP-PRJ-001324
RD4	Virtual Machine Compiler and Simulator	
RD5	MCU Command List	
RD6	DPU-BSW Software Requirement Document	DPU-SQ-CGS-001
RD7	Switch-on Procedure TM Packets User Manual	DPU-MA-CGS-004
RD8	VIRTUOSO User Guide	
RD9	ADSP-21000 Family C Tools Manual	

1.4 Document Change Record

Issue	Revision	Date	Reason for Change
1	1	26/11/2004	Updated list of event packets

2 OBS Compilation

This section describes the basic components that must be available to compile the OBS and the procedure to do it.

2.1 External Components

In order to be able to recompile the OBS two components must be installed on a Windows machine:

- ADSP- C Compiler and Tools (see RD9)
- VIRTUOSO Real-Time Software Development Tool (see RD8).

2.2 The VIRTUOSO Project File

The **spire.vpf** file contains the settings of the VIRTUOSO services that are used in the OBS. It can either be edited under VIRTUOSO, or with any text editor. This is where objects like Tasks, Semaphores, FIFO services, Events, Timers are defined. Refer to RD8 for a detailed description of the various services used. Here is the current content of the project file for version 1.2.J of the SPIRE OBS, that is part of the OBS distribution.

```
% Virtuoso Project File C:\Virtuoso\ADI21020\Rev33\Sigma\MyProj\spire.N1x\SPIRE.vpf
% Generated by Sysgen Backend version 4.1 R2.03 on Wed Nov 13 11:10:39 2002
% GLOBALPAR NAME      PARVALUE
% =====
GLOBALPAR TICKFREQ    1000
GLOBALPAR DATALEN    16384
GLOBALPAR CEILING_PRIO 4
GLOBALPAR KERNEL_PRIO 0
GLOBALPAR DRIVER_PRIO 0

% NLIFILE NLIFILEPATH
% =====
NLIFILE 'spire.nli'

% NODE NAME      NLINAME      NDPACKS NCPACKS NTIMERS KSTACK MONITSIZE MONITMASK
% =====
NODE NODE1      NODE1          16       100      20       256      512      0

% DRIVERTYPE     NODE      CALL
% =====
TIMERDRIVER     NODE1     'timer_driver (TMZHI)      '
USERDRIVER      NODE1     'StackOverFlowChecker(NULL) '

% NETLINK NODE1      CALL1          DIR NODE2      CALL2
% =====

% TASKGROUP NAME      STARTUP
% =====
TASKGROUP EXE         1
TASKGROUP SYS         1
```

```

TASKGROUP FPU          0
TASKGROUP EXE_NOBOOT  0
TASKGROUP VM_GROUP    1
TASKGROUP HK_GROUP    1

```

% TASK NAME	NODE	PRIO	ENTRY	STACK	GROUPS
% =====					
TASK INIT	NODE1	4	init	2048	[EXE]
TASK TIME_TASK	NODE1	4	time_tsk	1024	[EXE]
TASK TMTTC	NODE1	5	tmttc	2048	[EXE]
TASK VM_0	NODE1	5	vm_0	1024	[EXE_NOBOOT]
TASK VM_1	NODE1	5	vm_1	1024	[VM_GROUP]
TASK VM_2	NODE1	5	vm_2	1024	[VM_GROUP]
TASK VM_3	NODE1	5	vm_3	1024	[VM_GROUP]
TASK VM_AFX	NODE1	5	vm_AFX	1024	[EXE_NOBOOT]
TASK HS	NODE1	6	hs	8192	[EXE]
TASK DBG_SEQ	NODE1	7	dbg_seq	2048	[EXE_NOBOOT]
TASK VM_SVC	NODE1	7	vm_svc	4096	[EXE]
TASK LS	NODE1	7	ls	8192	[EXE]
TASK CMD_SEQ	NODE1	8	cmd_seq	4096	[EXE]
TASK HK_ASK0	NODE1	9	hk_ask0	2048	[HK_GROUP]
TASK HK_ASK1	NODE1	9	hk_ask1	2048	[HK_GROUP]
TASK HK_ASK2	NODE1	9	hk_ask2	2048	[HK_GROUP]
TASK HK_ASK3	NODE1	9	hk_ask3	2048	[HK_GROUP]
TASK HK_MON	NODE1	9	hk_mon	2048	[EXE_NOBOOT]
TASK AUTO_SEQ	NODE1	10	auto_seq	2048	[EXE]

% FIFO NAME	NODE	DEPTH	WIDTH
% =====			
FIFO TC_HP_QUEUE	NODE1	8	40
FIFO TC_LP_QUEUE	NODE1	8	40
FIFO EV_TM_QUEUE	NODE1	80	40
FIFO HK_TM_QUEUE	NODE1	32	40
FIFO SD_TM_QUEUE	NODE1	128	40
FIFO LS_HP_QUEUE	NODE1	64	16
FIFO LS_LP_QUEUE	NODE1	1024	16
FIFO AUTO_HP_QUEUE	NODE1	512	40
FIFO AUTO_LP_QUEUE	NODE1	512	40
FIFO VM_TM_QUEUE	NODE1	64	12

% EVENT NAME	NODE	CALL
% =====		
EVENT ISR_1553_EVENT	NODE1	'NULL'
EVENT ISR_FIFO_EVENT	NODE1	'NULL'
EVENT ISR_TIMER_EVENT	NODE1	'NULL'
EVENT TS_EVENT	NODE1	'NULL'
EVENT HK_0_EVENT	NODE1	'NULL'
EVENT HK_1_EVENT	NODE1	'NULL'
EVENT HK_2_EVENT	NODE1	'NULL'
EVENT HK_3_EVENT	NODE1	'NULL'
EVENT LS_TC_EVENT	NODE1	'NULL'
EVENT LS_0_EVENT	NODE1	'NULL'
EVENT LS_1_EVENT	NODE1	'NULL'
EVENT LS_2_EVENT	NODE1	'NULL'
EVENT LS_3_EVENT	NODE1	'NULL'

```
% MAP NAME      NODE      BLOCKS BLOCKSIZE
% =====
```

```
% SEMA NAME      NODE
% =====
SEMA HK_0_SEMA   NODE1
SEMA HK_1_SEMA   NODE1
SEMA HK_2_SEMA   NODE1
SEMA HK_3_SEMA   NODE1
SEMA LS_SEMA     NODE1
SEMA TC_READY    NODE1
SEMA FRAG_SEMA   NODE1
SEMA AUTO_SEMA   NODE1
SEMA DBG_SEMA    NODE1
```

```
% MAILBOX NAME   NODE
% =====
```

```
% RESOURCE NAME      NODE
% =====
RESOURCE TIMER_RESOURCE NODE1
```

```
% POOL NAME      NODE      SIZE_SMALL SIZE_LARGE BLOCK_NUMBER
% =====
```

2.3 The Architecture File

The **spire.ach** file contains the definition of the various segments of the DPU PM and DM. Here is the current content of the architecture file for the version 1.2.J of the SPIRE OBS, that is part of the OBS distribution. Refer to RD9 for a detailed description of the various segments and directives used in creating this file.

```
!=====
.system FirstDPU;
.processor = ADSP21020;
! Program Memory
!==== Interrupt table
.segment /pm /ram /begin=0x000000 /end=0x0000FF seg_rth;
!==== Code
.segment /pm /ram /begin=0x004000 /end=0x004FFF seg_init;
.segment /pm /ram /begin=0x005000 /end=0x07FFFF seg_pmco;
! Data Memory
.segment /dm /ram /begin=0x00000000 /end=0x0004FFFF seg_dmda;
.segment /dm /ram /begin=0x00050000 /end=0x000503FF /cstack seg_stak;
.segment /dm /ram /begin=0x00050400 /end=0x0007FFFF /cheap heap1;
!
.segment /dm /ram /begin=0x40000000 /end=0x400FFFFF 1355_IF;
.segment /dm /ram /begin=0x80000000 /end=0x8003FFFF EEPROM;
.segment /dm /port /begin=0x81000000 /end=0x81FFFFF Timer;
.segment /dm /port /begin=0x82000000 /end=0x82FFFFF watchdog;
.segment /dm /port /begin=0x83000000 /end=0x83FFFFF Int_mng;
.segment /dm /ram /begin=0x84000000 /end=0x84FFFFF SMCS_reg;
.segment /dm /ram /begin=0x88000000 /end=0x8FFFFF Bus_IF;
```

```

!=====
!Bank Description
!the PM bank1 is not mounted
.bank /pm0 /wtstates=0 /wtmode=internal /begin=0x0000000;
!
! DM bank 0 is used for data storing
! DM bank 1 is reserved for Mezzanine IF and it is not used
! DM bank 2 is reserved for IEEE 1355
! DM bank 3 is reserved for the following register and Device
!
!                               EEPROM, Interval Timer, Watchdog, Interrupt Manager
!                               SMCS332 register, 32 bit bus interface
.bank /dm0 /wtstates=0 /wtmode=internal /begin=0x00000000;
.bank /dm1 /wtstates=1 /wtmode=both /begin=0x20000000;
.bank /dm2 /wtstates=0 /wtmode=internal /begin=0x40000000;
.bank /dm3 /wtstates=1 /wtmode=both /begin=0x80000000;
!=====
.endsys;
!***** end of file *****

```

2.4 Compiling the OBS

The OBS distribution contains a **makefile** that manages the compilation and linking of the source code. Typing **make** on the command line will compile all source files that have been updated with respect to previous compilation, or that depend on include files that have been modified; **make rebuild** will recompile all C and Assembler source code files.

Any compilation subsequent to a modification of the VIRTUOSO Project File (e.g. after adding another semaphore) will need a valid VIRTUOSO license.

2.5 The Compilation Products

The compilation will produce many intermediate files. The .o object files whose name starts with the suffix MIL should never be deleted since they contain the compiled MIL-1553B-STD drivers whose source codes are not included in the OBS delivery.

The most important compilation product is obviously the **SPIRE.EXE** that will contain the executable code.

Another useful output file is the memory map file that documents the actual DPU memory usage by the OBS. Here is an extract from the **SPIRE.MAP** file contained in the OBS distribution and valid for the version 1.2.J of the SPIRE OBS.

```

Analog Devices ADSP-210x0 Linker      spire.map      Page 1
Release 3.3, Version 2.21             Thu Aug 19 10:26:32 2004
Copyright (c) 1991-1996 Analog Devices, Inc.

```

Architecture Description: FirstDPU

Segment	Start	End	Length	Memory Type	Attribute
seg_rth	000000	0000ff	256	Program Memory	RAM
seg_dmda	00000000	0004ffff	327680	Data Memory	RAM
seg_init	004000	004fff	4096	Program Memory	RAM
seg_pmco	005000	07ffff	503808	Program Memory	RAM
seg_stak	00050000	000503ff	1024	Data Memory	RAM

heap1	00050400	0007ffff	195584	Data Memory	RAM
1355_IF	40000000	400fffff	1048576	Data Memory	RAM
EEPROM	80000000	8003ffff	262144	Data Memory	RAM
Timer	81000000	81ffffff	16777216	Data Memory	PORT
watchdog	82000000	82ffffff	16777216	Data Memory	PORT
Int_mng	83000000	83ffffff	16777216	Data Memory	PORT
SMCS_reg	84000000	84ffffff	16777216	Data Memory	RAM
Bus_IF	88000000	8fffffff	134217728	Data Memory	RAM

Memory Usage (Actual):

Segment	Start	End	Length	Memory Type	Attribute
seg_rth	000000	0000ff	256	Program Memory	RAM
seg_init	004000	00400e	15	Program Memory	RAM
seg_pmco	005000	01151e	50463	Program Memory	RAM
seg_dmda	00000000	0004abb4	306101	Data Memory	RAM
seg_stak	00050000	0005000a	11	Data Memory	RAM
heap1	*****	*****	0	Data Memory	RAM
1355_IF	*****	*****	0	Data Memory	RAM
EEPROM	*****	*****	0	Data Memory	RAM
Timer	*****	*****	0	Data Memory	PORT
watchdog	*****	*****	0	Data Memory	PORT
Int_mng	*****	*****	0	Data Memory	PORT
SMCS_reg	*****	*****	0	Data Memory	RAM
Bus_IF	*****	*****	0	Data Memory	RAM

Memory Usage Summaries:

Memory Type	Attribute	Total
Program Memory	ROM	0
Program Memory	RAM	50734
Program Memory	PORT	0
Data Memory	ROM	0
Data Memory	RAM	306112
Data Memory	PORT	0

3 OBS Loading on the DPU

When the DPU is switched on, the BSW is copied from PROM to PM and run. The details of the boot procedure can be found elsewhere (see RD6); here we simply note that after all the tests are carried out, a (5,2) event is generated and the boot enters an infinite loop waiting for a TC. The contents of the generated event are described in RD7; the last word in the packet contains the number of errors found in the memory checks, and should be 0. At this point there are two modes of loading and executing the OBS: using the image resident on the EEPROM on-board, or loading a new image via standard TCs.

3.1 Running the EEPROM-resident OBS

The OBS is resident in EEPROM. Once the (5,2) event (with no errors reported) is received by the CDMS simulator, the command “Force boot” described in RD2 can be sent to the DPU; the BSW will copy the OBS from EEPROM to PM, jump at the start location of the OBS in the PM, and the OBS will start running. If the DPU is connected to the CDMS simulator or SCOS2000, HK packets will be received (SIDs 0x300 and 0x301). This can be considered as the confirmation that the startup procedure has been successfully completed.

3.2 Loading the OBS via Telecommands

Once the BSW puts the DPU in a wait state, it is possible to uplink from SCOS2000 a new image of the OBS using standard TCs. The C program **TCGen** provided by Gavazzi is available under Windows to translate the OBS image SPIRE.EXE into a list of TC (6,2) ready to be sent to the DPU. The ADI21020 C Compiler must also be installed, since TCGen uses some C-tools (like cdump). The command to invoke the procedure is:

```
>tcgen -i segfile.txt -p pagefile.txt -f SPIRE.EXE -a 0x500 -o path/suffix -m 0
```

the *segfile* file contains the list of memory segments (one per line) defined in the program memory of the DPU and reported in the architecture file (*spire.ach*); typically the segments are *seg_rth*, *seg_init* and *seg_pmco*.

The *pagefile* file contains the list of memory pages to be avoided (it can be empty).

OBS.EXE is the executable file as produced by the compilation of the OBS code.

Path is the directory where the output TCs will be stored and *suffix* is a string that will be attached to the TC file names: the output files will be named *suffixTCnnnnn.dm* where *nnnnn* is a count number.

Once the set of TCs containing the image of the OBS have been produced, they can be uplinked using the “**ObswLoader**” script. The script loads TCs from a local directory and sends them to the CDMS that, in turn, sends them to the DPU. The following syntax should be used to invoke the script.

```
> ObswLoader -dpu -apid 1280 -interval XXX path/*
```

where *path* is the directory that hosts the telecommands prepared with the TCGen program, and *XXX* is the interval in milliseconds for the dispatch of subsequent TCs to the CDMS. Clearly, the dispatching interval should match the capabilities of the buslist currently running on the CDMS. For fast uploads a dedicated buslist has been prepared that allows the CDMS to send to the DPU a maximum of 20 TC/s; using this buslist allows to invoke the **ObswLoader** script with an interval parameter of 50 (milliseconds). If one uses the nominal buslist where only 2 TC/s can be uplinked, then the interval parameter should be set to 500.

Once all TCs have been sent, it will be necessary to send the “Load TC and boot” TC (see RD2) from SCOS2000 to command the BSW to copy the full image from DM to PM and start the application program. If large areas of DM are damaged so that there is not enough space to store the image before copying it in PM, it is possible to upload a subset of TC. After any subset has been uploaded, the command to send is “Load TC and wait”: when the BSW receives this command, this part of the image is copied in PM but the application program is not started. The BSW waits for the next subset and so on. When the last subset of memory packets is received, by sending the command “Load TC and boot” the DPU copies this last piece of code and then

starts the execution of the application software. This command has not been tested so far and it should not be used.

It is also possible to restart the Boot Software, and thus reload the EEPROM-stored OBS or up-link the OBS via TCs, without switching off and on again the DPU: this can be done while the OBS is running by sending the “Call Boot” telecommand from SCOS2000.

4 Runtime Instructions

4.1 Telecommand Verification

The generation of the telecommand verification packets TM (1,3) (Execution Start), TM (1,5) (Execution Progress) and TM (1,7) (Execution End) are controlled by the Ack bits in the TC sent to the DPU, as specified in AD3 (§3.1). The TM (1,1) (successful TC verification), TM (1,2) (unsuccessful TC verification) and TM (1,8) (Execution Failure) are issued by the OBS irrespectively of the TC Ack bits. The actual dispatching of these TM packets to the CDMS can be inhibited using service 14 (Packet Transmission Control) as specified in AD3.

Error codes contained in TM (1,2) are listed in AD3, while error codes in TM (1,8) are reported in RD2.

4.2 Housekeeping Data Reporting

The OBS only generates HK packets TM (3,25). No Diagnostic packets are generated. The HK packet definition is stored in tables in the OBS. Four independent HK packets can be generated simultaneously, each with its own sampling interval.

HK Packet ID	Packet
0	Essential HK Packet
1	Nominal HK Packet. A subset of the parameters contained in this packet will be used for monitoring.
2	Free
3	Free

Table 4-1 List of allowed HK packets

The OBS does not perform any check on the DPU workload implied by the HK parameters collection. In particular, it should be remembered that the minimum time to issue a HK parameter request to the DRCU and receive the correspondent parameter is 2 milliseconds. This means that nominally the cumulative number of DRCU parameters requested for the various HK packets should not exceed 500/sec to avoid losing data. In reality the number should be kept below that limit because the OBS will likely be performing other tasks requiring communication to the sub-systems at the same time.

4.2.1 Situation at Start-Up

At OBS start-up two types of HK packets are generated by default: the critical HK packet and the nominal HK packet. Both packets are TM (3,25) and the header only differs for the APID (0x0500 and 0x0502 respectively) and for the SID (0x0300 and 0x0301 respectively). The two

packets are issued every 2s and every 1s respectively. The definition of the two packets is loaded on OBS initialisation and complies with requirements contained in RD2.

4.2.2 Modifying the HK Packet Properties

4.2.2.1 Sampling Interval

The sampling interval of an HK packet can be modified via a TC (8,4,0xCC-01), inserting the required interval in milliseconds in the proper TC field as specified in RD2. the new sampling interval is applied at the start of HK sampling cycle immediately following TC (8,4, 0xCC-01) reception. This means that if the current sampling interval of an HK packet is 10 seconds and a TC (8,4, 0xCC-01) with a 1 second sampling interval is received 2 seconds after the last HK packet has been issued, the 1-second HK packets will start to be sent after about 8 seconds from TC reception.

4.2.2.2 HK Packet Contents

The contents of the HK packets are defined by on-board tables that contain the list of DRCU 32-bits command words needed to get those parameters. The order in which the commands are stored in the HK definition tables defines the order in which the HK parameters are stored in the HK packets. To modify the contents of an HK packet, the first thing to do is then to uplink a new table (with its own ID number) containing the list of 32-bits commands needed to get the required HK parameters. The sequence of actions is then the following:

- a) Load a new HK definition Table. The mechanism to do this will be explained when dealing with Tables management.
- b) Stop HK acquisition using a TC (8,4, 0xCC-02) with the required HK Packet ID as specified in RD2.
- c) Restart HK acquisition using a TC (8,4, 0xCC-01) with the required HK Packet ID, the Table ID of the table uplinked in a) and the required sampling interval in milliseconds.

Warning: since the Nominal HK packet (ID 0x301) will be used for monitoring purposes, stopping HK Packet ID 0x301 will also stop the monitoring task. Besides, when redefining the table to be used for Nominal HK packet, particular care must be applied in making sure that no parameter used by the monitoring task is removed from the HK packet definition.

Note: A TC (8,4, 0xCC-01) with a Table ID different from the one currently in use for that HK Packet ID must be preceded by a TC (8,4,0xCC-02), or a TM (1,8) with code 0x0827 (RD2) will be issued.

The list of commands for the DRCU is reported in RD3 and RD5. The commands to get DPU internal HK parameters are built according to the same structure (see AD2) so that the HK acquisition task can handle both types of HK requests. The list of available commands to get DPU HK parameters is the following:

Command ID	Function	N bits	Content
0x20010000	Get Observation ID	32	

0x20020000	Get Building Block ID	32	
0x10030000	Get Observing Mode	16	
0x10040000	Get Observation Step	16	
0x30050000	Get time of last DRCU timer reset	48	
0x30060000	Get Last Time Stamp	48	
0x30070000	Get absolute time drift	48	Time difference between last CDMS Time Stamp and OBS internal clock
0x30080000	Get Time of Start HK0 parameters collection	48	
0x30090000	Get Time of Start HK1 parameters collection	48	
0x300A0000	Get Time of Start HK2 parameters collection	48	
0x300B0000	Get Time of Start HK3 parameters collection	48	
0x100C0000		16	*
0x100D0000	Get number of received TC	16	
0x100E0000	Get sequence number of last received TC	16	
0x100f0000	Get number of executed TC	16	
0x10100000	Get sequence number of last executed TC	16	
0x20110000	Get observation length in seconds	32	
0x20120000	Get data rate of current observation in byte/s	32	
0x30130000	Get Memory check info (NYI)	16	*
0x04140000	Get monitoring flags	16	The 3 LSBs report subsystems activation status in "SCU, MCU, DCU" order
0x10150000	Get DCU flags (NYI)	16	*
0x10160000	Get SCU flags (NYI)	16	*
0x10170000	Get MCU flags (NYI)	16	*
0x04180000	Get number of packet sent under Apid1	16	
0x04190000	Get number of packet sent under Apid2	16	
0x041A0000	Get number of packet sent under Apid3	16	
0x041B0000	Get number of packet sent under Apid4	16	
0x041C0000	Get number of packet sent under Apid5	16	
0x101D0000		16	*
0x101E0000		16	*
0x101F0000		16	*
0x10200000	(RESERVED)		
0x04210000	Get DPU 5V	16	
0x04220000	Get DPU 15V	16	
0x04230000	Get DPU -15V	16	
0x04240000	Get DPU temperature	16	
0x10250000	(RESERVED)		
0x10260000	(RESERVED)		
0x04270000	Get DPU 2.5V	16	
0x04280000	Get DPU processor workload	16	units per thousand
0x08290000	Get LS internal queue Workload	32	Single LS command
0x102A0000	Get DCU fifo frame counter	16	
0x102B0000	Get MCU fifo frame counter	16	
0x102C0000	Get SCU fifo frame counter	16	
0x102D0000	Get Event status (NYI)	16	*
0x102E0000	Get Tm Mode (NYI)	16	*
0x102F0000	Get LS channel duty time (NYI)	32	In microsecond
0x10300000			*
0x10310000			*
0x10320000			*
0x10330000			*
0x10340000			*

0x10350000			*
0x10360000			*
0x10370000			*
0x10380000	Get Hard VM 0 status (NYI)	16	*
0x10390000	Get Soft VM 1 status (NYI)	16	*
0x103A0000	Get Soft VM 2 status (NYI)	16	*
0x103B0000	Get Soft VM 3 status (NYI)	16	*
0x103C0000	GetSCPoolStat	16	N. of slots available
0x103D0000	GetHKPoolStat	16	Ibidem
0x103E0000	GetEVPoolStat	16	Ibidem
0x103F0000	GetRPPoolStat	16	Ibidem
0x04400000	Get_HUP_Task_State	16	RUNNING 0x0000 STOPPED 0x0001 ABORTED 0x0003 SUSPEND 0x0004 SLEEPING 0x0010 EVENT_W 0x0080 FIFO_W 0x0200 SEMA_W 0x1000 Unknown 0xFFFF
0x04410000	Get_INIT_Task_State	16	Ibidem
0x04420000	Get_TIME_Task_State	16	Ibidem
0x04430000	Get_TMTC_Task_State	16	Ibidem
0x04440000	Get_VM_0_Task_State	16	Ibidem
0x04450000	Get_VM_1_Task_State	16	Ibidem
0x04460000	Get_VM_2_Task_State	16	Ibidem
0x04470000	Get_VM_3_Task_State	16	Ibidem
0x04480000	Get_VM_AFX_Task_State	16	Ibidem
0x04490000	Get_HS_Task_State	16	Ibidem
0x044A0000	Get_DBG_SEQ_Task_State	16	Ibidem
0x044B0000	Get_VM_SVC_Task_State	16	Ibidem
0x044C0000	Get_LS_Task_State	16	Ibidem
0x044D0000	Get_CMD_SEQ_Task_State	16	Ibidem
0x044E0000	Get_HK_ASK0_Task_State	16	Ibidem
0x044F0000	Get_HK_ASK1_Task_State	16	Ibidem
0x04500000	Get_HK_ASK2_Task_State	16	Ibidem
0x04510000	Get_HK_ASK3_Task_State	16	Ibidem
0x04520000	Get_HK_MON_Task_State	16	Ibidem
0x04530000	Get_AUTO_SEQ_Task_State	16	Ibidem
0x04540000	Get_TABLER_Task_State	16	Ibidem
0x04550000	Get_TUP_Task_State	16	Ibidem
0x10560000	[Beginning of free slots]		*
0x105F0000	[Ending of free slots]		*
0x10600000	Get_DPU_Stat	16	OBS Version
0x10610000	GetTmMode	16	Nominal/BurstMode
0x10620000	[Beginning of free slots]		*
0x10FE0000	[Ending of free slots]		*
0x10FF0000	Dummy place holder	16	* Always 0 (zero)

Table 4-2 Commands to get DPU HK parameters

4.3 Memory Management

4.3.1 Absolute Addressing

Loading and dumping of memory areas using absolute addresses can be performed using the dedicated TCs of Service 6 as described in AD3 and RD2. The `Start_Address` parameter in the TC (6,2) is a relative address for each allowed memory area identified by the `Memory_ID` parameter. The allowed Memory IDs are listed in RD2.

4.3.2 Table Management

All HK packet definitions and VM codes needed to perform the SPIRE observations (see AD2 for a description of the concept) are stored on-board as Tables. Each table is characterised by an ID and a length in 32-bits words. The absolute memory addresses of all on-board tables are managed by the OBS and are not available to the user. The TCs to load and delete on-board tables are described in RD2. Here we describe how to use those TCs.

4.3.2.1 Table Load

The sequence to load a new table is the following:

- a) Send a TC (8,4, 0x01-0x01) specifying the Table ID and the length in 32-bits words of the Table.
Warning: if the specified Table ID exists, the table is deleted. The only exception is if the table is in use (by an HK-collection task or VM), in which case a TM (1,8) is issued with a *Busy_table* error code.
- b) Send a TC (8,4, 0x01-0x03) containing the list of 32-bits words. Since the TC holds 16-bits words, each 32-bits word will have to be split in two, with the MSBs preceding the LSBs. The number of the 32-bits words contained in the TC must not exceed the length specified in a) for that Table ID, or a *Bad_NData* TM (1,8) will be generated.

4.3.2.2 Table Update

To update an existing table it is sufficient to send a TC (8,4, 0x01-0x03) as specified in b) of 4.3.2.1.

4.3.2.3 Table Delete

To delete an existing table it is sufficient to send a TC (8,4, 0x01-0x01) specifying the Table ID and setting the length to 0.

Note: if the table is in use (HK packet or VM code) a TM (1,8) will be issued.

4.3.3 Table Defragmentation

Tables are stored in a dedicated DM area. After a while the continuous creation, update and deletion of tables may lead to an excessive memory fragmentation within that area. This may result in the inability to create new tables even when enough space is available but it is not contiguous. The OBS can defragment the DM either automatically when the free and contiguous space of the DM area dedicated to tables is less than 20%, or via a dedicated TC (8,4, TBD-TBD).

4.4 Virtual Machine Programs

VM programs are stored in tables in a dedicated DM area. RD4 describes how to write and compile a VM program using a GUI available under windows. The GUI is able to produce the executable VM code already organised in TC (8,4, 0x01-0x01) ready to be sent to the DPU.

5 Event Reporting

Warning event TM (5,x) packets are issued by the OBS in several occasions. Here follows a table of warning/exception conditions so far identified and that result in the generation of a TM (5,x) packet.

TM Packet	Event Code	SID	Event Name	Explanation	Returned Parameters
(5,1)	0x0501	0x5100	REPORT_STEP	Indicates a new step in the current operation Mode. This event is issued every time the MODE or STEP Number is changed	<ul style="list-style-type: none"> • Current Mode • Current Step Number
(5,1)	0x0504	0x5101	REPORT_PEAKUP	(NYI)	<ul style="list-style-type: none"> • (NYI)
(5,1)	0x0505	0x5102	BLOCK_NOT_ALLOCATED	OBS cannot allocate a required memory block in DM. VIRTUOSO memory blocks are allocated from the DM heap. The maximum number of blocks is specified in the architecture file and is sized to the available DM. This event may imply that memory blocks in use are not being released fast enough, and in this case it should be preceded by event 0x050d.	<ul style="list-style-type: none"> • ID of Pool • Size in Bytes of the required block • Result of block allocation: <ul style="list-style-type: none"> ○ 1: Failed ○ 2: Timed-out • ID of OBS Task that requires the block • # of Packets currently present in pool • Maximum # of packets in pool
(5,1)	0x0506		Not Assigned		
(5,1)	0x0507		Not Assigned		
(5,1)	0x0508		Not Assigned		
(5,1)	0x0509	0x5103	ERROR_LS_CID_UNKNOWN	In response to a "SET" command, the DRCU notifies that the command ID is not known.	<ul style="list-style-type: none"> • 32-bits Command sent to the DRCU • 32-bits echo received
(5,1)	0x050a	0x5104	ERROR_LS_CID_FORBIDDEN	In response to a "SET" command, the DRCU notifies that the command ID is forbidden.	<ul style="list-style-type: none"> • 32-bits Command sent to the DRCU • 32-bits echo received
(5,1)	0x050b	0x5108	ERROR_SS_TIMEOUT	In response to a "SET" command, the DRCU times out.	<ul style="list-style-type: none"> • 32-bits Command sent to the DRCU • 32-bits echo received
(5,1)	0x050c	0x5109	ERROR_LS_DRCU_RX	The 2 MSB of the echo sent back by the DRCU in response to a "GET" command, are not identical to the pattern sent by the DPU. In this case the parameter cannot be trusted and is discarded.	<ul style="list-style-type: none"> • 32-bits Command sent to the DRCU • 32-bits echo received
(5,1)	0x050d		Not Assigned		

(5,1)	0x050e		Not Assigned		
(5,1)	0x050f	0x510C	ERROR_LS_OVERFLOW	The number of commands sent to the DRCU (HK collection + all VMs) exceeds the maximum allowed rate.	<ul style="list-style-type: none"> 32-bits word with number of microseconds in which the LS port was busy during the last second (should be more than 10⁶)
(5,1)	0x0510	0x510D	UNKNOWN_TM_PKT	A TM packet ready to be sent has an unknown combination of type, subtype and SID.	<ul style="list-style-type: none"> Type, subtype and SID of the unknown TM packet
(5,1)	0x0511	0x5111	TC_SEQ_ERROR	A gap in TC Packet counter of the TC PTD has been detected.	<ul style="list-style-type: none"> Previous TC PTD Counter. Currently read TC PTD counter
(5,1)	0x0520	0x510E	ERROR_NO_DCU_RES	The DCU DRCU does not respond to a command. This event is raised when the status bit 2 in the LS port status register is not asserted within 2 milliseconds from the command dispatch to the DRCU, or when the response read doesn't match with sent command, this might as well imply that the LS Hardware interface is not working correctly.	<ul style="list-style-type: none"> Command sent to the DRCU
(5,1)	0x0521	0x510F	ERROR_NO_MCU_RES	As NO_DCU_RES error, but for MCU subsystem	<ul style="list-style-type: none"> Command sent to the DRCU
(5,1)	0x0522	0x5110	ERROR_NO_SCU_RES	As NO_DCU_RES error, but for SCU subsystem	<ul style="list-style-type: none"> Command sent to the DRCU
(5,1)	0x1500	0x510A	ERROR_TC_POOL_FULL_ID	The DPU Memory Pool for Telecommand packets is more than 80% full	<ul style="list-style-type: none"> Pool ID Pool occupation status Pool occupation limit
(5,1)	0x1501	0x510A	ERROR_EV_POOL_FULL_ID	The DPU Memory Pool for Event TM packets is more than 80% full	<ul style="list-style-type: none"> Pool ID Pool occupation status Pool occupation limit
(5,1)	0x1502	0x510A	ERROR_HK_POOL_FULL_ID	The DPU Memory Pool for HouseKeeping TM packets is more than 80% full	<ul style="list-style-type: none"> Pool ID Pool occupation status Pool occupation limit
(5,1)	0x1503	0x510A	ERROR_SD_POOL_FULL_ID	The DPU Memory Pool for Science TM packets is more than 80% full	<ul style="list-style-type: none"> Pool ID Pool occupation status Pool occupation limit

(5,1)	0x1510	0x510B	ERROR_TC_HP_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for high-priority TC packets is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1511	0x510B	ERROR_TC_LP_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for low-priority TC packets is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1512	0x510B	ER-ROR_EV_TM_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for event TM packets is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1513	0x510B	ER-ROR_HK_TM_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for HouseKeeping TM packets is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1514	0x510B	ER-ROR_SD_TM_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for science TM packets is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1515	0x510B	ERROR_LS_HP_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for high-priority Sub-Systems commands is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1516	0x510B	ERROR_LS_LP_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for low-priority Sub-Systems commands is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x1519	0x510B	ER-ROR_VM_TM_FIFO_FULL_ID	The VIRTUOSO FIFO Queue for TM packets generated by the VM is more than 80% full	<ul style="list-style-type: none"> • FIFO ID • FIFO occupation status • FIFO occupation limit
(5,1)	0x2578	0x5105	ERROR_FIFO_DCU_FID_ID	Wrong Frame ID in science data received from DCU	<ul style="list-style-type: none"> • HW Fifo ID • Frame ID read
(5,1)	0x2579	0x5105	ERROR_FIFO_MCU_FID_ID	Wrong Frame ID in science data received from MCU	<ul style="list-style-type: none"> • HW Fifo ID • Frame ID read
(5,1)	0x257A	0x5105	ERROR_FIFO_SCU_FID_ID	Wrong Frame ID in science data received from SCU	<ul style="list-style-type: none"> • HW Fifo ID • Frame ID read
(5,1)	0x2540	0x5106	ER-ROR_FIFO_DCU_FLEN_PHOT_FULL_ID	Wrong Frame Length for a Full Photometry DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID

(5,1)	0x2541	0x5106	ER-ROR_FIFO_DCU_FLEN_SPEC_FULL_ID	Wrong Frame Length for a Full Spectrometer DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2542	0x5106	ER-ROR_FIFO_DCU_FLEN_PSW_ID	Wrong Frame Length for a PSW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2543	0x5106	ER-ROR_FIFO_DCU_FLEN_PMW_ID	Wrong Frame Length for a PMW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2544	0x5106	ER-ROR_FIFO_DCU_FLEN_PLW_ID	Wrong Frame Length for a PLW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2545	0x5106	ER-ROR_FIFO_DCU_FLEN_SSW_ID	Wrong Frame Length for a SSW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2546	0x5106	ER-ROR_FIFO_DCU_FLEN_SLW_ID	Wrong Frame Length for a SLW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2547	0x5106	ER-ROR_FIFO_DCU_FLEN_PHOT_OFF_ID	Wrong Frame Length for a Full Photometry Offset DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2548	0x5106	ER-ROR_FIFO_DCU_FLEN_SPEC_OFF_ID	Wrong Frame Length for a Full Spectrometer Offset DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2549	0x5106	ER-ROR_FIFO_DCU_FLEN_PHOT_FULL_TEST_ID	Wrong Frame Length for a Full Photometry Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x254A	0x5106	ER-ROR_FIFO_DCU_FLEN_PSW_TEST_ID	Wrong Frame Length for a PSW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x254B	0x5106	ER-ROR_FIFO_DCU_FLEN_PMW_TEST_ID	Wrong Frame Length for a PMW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID

(5,1)	0x254C	0x5106	ER-ROR_FIFO_DCU_FLEN_PLW_T EST_ID	Wrong Frame Length for a PLW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x254D	0x5106	ER-ROR_FIFO_DCU_FLEN_SPEC_ FULL_TEST_ID	Wrong Frame Length for a Full Spectrometer Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x254E	0x5106	ER-ROR_FIFO_DCU_FLEN_SSW_T EST_ID	Wrong Frame Length for a SSW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x254F	0x5106	ER-ROR_FIFO_DCU_FLEN_SLW_T EST_ID	Wrong Frame Length for a SLW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2550	0x5107	ER-ROR_FIFO_DCU_FCRC_PHOT_ FULL_ID	Wrong checksum for a Full Photometry DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2551	0x5107	ERROR_FIFO_DCU_FCRC _SPEC_FULL_ID	Wrong checksum for a Full Spectrometer DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2552	0x5107	ERROR_FIFO_DCU_FCRC _PSW_ID	Wrong checksum for a PSW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2553	0x5107	ERROR_FIFO_DCU_FCRC _PMW_ID	Wrong checksum for a PMW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2554	0x5107	ERROR_FIFO_DCU_FCRC _PLW_ID	Wrong checksum for a PLW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2555	0x5107	ERROR_FIFO_DCU_FCRC _SSW_ID	Wrong checksum for a SSW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2556	0x5107	ERROR_FIFO_DCU_FCRC _SLW_ID	Wrong checksum for a SLW DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2557	0x5107	ERROR_FIFO_DCU_FCRC _PHOT_OFF_ID	Wrong checksum for a Full Photometry Offset DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum
(5,1)	0x2558	0x5107	ERROR_FIFO_DCU_FCRC _SPEC_OFF_ID	Wrong checksum for a Full Spectrometer Offset DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed check-sum • Read checksum

(5,1)	0x2559	0x5107	ERROR_FIFO_DCU_FCRC_PHOT_FULL_TEST_ID	Wrong checksum for a Full Photometry Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x255A	0x5107	ERROR_FIFO_DCU_FCRC_PSW_TEST_ID	Wrong checksum for a PSW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x255B	0x5107	ERROR_FIFO_DCU_FCRC_PMW_TEST_ID	Wrong checksum for a PMW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x255C	0x5107	ERROR_FIFO_DCU_FCRC_PLW_TEST_ID	Wrong checksum for a PLW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x255D	0x5107	ERROR_FIFO_DCU_FCRC_SPEC_FULL_TEST_ID	Wrong checksum for a Full Spectrometer Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x255E	0x5107	ERROR_FIFO_DCU_FCRC_SSW_TEST_ID	Wrong checksum for a SSW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x255F	0x5107	ERROR_FIFO_DCU_FCRC_SLW_TEST_ID	Wrong checksum for a SLW Test DCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x2560	0x5106	ER-ROR_FIFO_MCU_FLEN_SMEC_ID	Wrong Frame Length for a SMEC MCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2561	0x5106	ER-ROR_FIFO_MCU_FLEN_BSM_ID	Wrong Frame Length for a BSM MCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2563	0x5106	ER-ROR_FIFO_MCU_FLEN_ENGINEERING_ID	Wrong Frame Length for an Engineering MCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2565	0x5106	ER-ROR_FIFO_MCU_FLEN_TEST_ID	Wrong Frame Length for a Test MCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2568	0x5107	ER-ROR_FIFO_MCU_FCRC_SMEC_ID	Wrong checksum for a SMEC MCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x2569	0x5107	ERROR_FIFO_MCU_FCRC_BSM_ID	Wrong checksum for a BSM MCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum

(5,1)	0x256B	0x5107	ERROR_FIFO_MCU_FCRC_ENGINEERING_ID	Wrong checksum for an Engineering MCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x256D	0x5107	ERROR_FIFO_MCU_FCRC_TEST_ID	Wrong checksum for a Test MCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x2570	0x5106	ER-ROR_FIFO_SCU_FLEN_HSK_ID	Wrong Frame Length for a nominal SCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2571	0x5106	ER-ROR_FIFO_SCU_FLEN_TEST_ID	Wrong Frame Length for a Test SCU frame	<ul style="list-style-type: none"> • Frame ID read • Frame length read • Expected Frame length for that Frame ID
(5,1)	0x2574	0x5107	ER-ROR_FIFO_SCU_FCRC_HSK_ID	Wrong checksum for a nominal SCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	0x2575	0x5107	ER-ROR_FIFO_SCU_FCRC_TEST_ID	Wrong checksum for a Test SCU frame	<ul style="list-style-type: none"> • Frame ID read • Computed checksum • Read checksum
(5,1)	vmArg	0x5113	EVENT_VM_EVENT	An Event Report from VM	<ul style="list-style-type: none"> • VM Arg.
(5,2)	0xC000	0x0520	EXCP_DRCU_ANOMALY_SID	(NYI)	<ul style="list-style-type: none"> • (NYI)
(5,2)	0xC010	0x0520	EXCP_DPU_ANOMALY_SID	(NYI)	<ul style="list-style-type: none"> • (NYI)
(5,2)	0xC100	0x0520	EXCP_OBS_ANOMALY_SID	(NYI)	<ul style="list-style-type: none"> • (NYI)
(5,2)	0xC110	0x0520	EXCP_OBS_CORRECT_SID	(NYI)	<ul style="list-style-type: none"> • (NYI)
(5,2)	0x0832	0x0520	EXCP_FX_UNARMED_SID	Cannot execute the activity requested, the function wasn't activated.	None
(5,2)	vmArg	0x5201	EXCP_VM_EXCP	An Event Exception Report from VM	<ul style="list-style-type: none"> • VM Arg.

Table 5-1 Event Warning/Error Codes

6 TC Verification Error Codes

In case of errors in the application data of the received telecommands, the DPU, in accordance with AD3, issues TM (1,8) packets. These packets will contain an error code and a variable list of parameters according to the following table.

Error Code	Error Name	Description	Parameters
Memory Management			
0x601	Illegal_Memory_ID	The specified Memory ID is not in the valid range 0-3	The requested Mem_ID
0x602	Illegal_Start_Address	The Start Address is not in the valid range for the requested Memory ID (see below)	Required Start Address
0x603	Illegal_NSAU	The uplinked number of SAUs will place the memory patch outside the valid range for the requested Memory ID and Start Address	Uplinked number of SAUs
0x604	Bad_NSAU	The number of SAUs does not match with the TC packet length contained in the TC packet header	Uplinked number of SAUs
0x605	Bad_CRC	The CRC computed by the OBS on the uplinked memory patch is not equal to the one sent with the TC	CRC value uplinked with the memory patch
0x606	Bad_Load	The CRC computed by the OBS after the memory patch has been written into the DPU memory is not equal to the CRC value in the TC which contained the memory patch	OBS computed CRC

Function Management			
0x805	Illegal_Table_ID	The Table specified is not in the valid 0-127 range	The required Table ID
0x806	Illegal_Table_Index	The INDEX in the <i>Update Table</i> TC is larger than the table length specified in the <i>Set Table</i> TC	The uplinked INDEX
0x807			
0x808	Bad_Data	The number of data words contained in the TC is not consistent with the Length field in the TC packet header	The uplinked number N of 32-bit data words
0x809	Table_Space_Full	Not enough memory to create the table of the required size (in the <i>Set Table</i> TC)	Required table length
0x80A	No_Command_List	A Stop VM TC has been received, but the specified VM is not running	The index of the VM (0 for HW VM) required to stop
0x80C	VM_Running	An <i>Execute</i> or <i>Start Command List</i> TC was received, but the specified VM is already executing a command list	The index of the VM (0 for HW VM) required to stop
0x80D	Bad_Ndata	The number of data words in a Report Table or Update Table TCs is inconsistent with the actual table length and start Index	The uplinked number (in units of 32-bit words) of data words
0x80E	LS_RECEPTION_ERROR	If a <i>Reset DRCU Counter</i> TC was received but the command could not be successfully dispatched to the DRCU because of an LS transmission error, this error code notifies that no DRCU sync was done	The sync DRCU command sent
0x80F	ILLEGAL_FFLAGS	The FIFO ID required to be reset is not a valid FIFO ID	The uplinked FIFO flag word
0x810	VM_UNDEFINED_TABLE_ID	The Table ID specified as input for a VM was not previously defined	The requested Table ID

0x811	Undefined_Table	The table for which an update or report has been requested, was not previously defined	The requested Table ID
0x812	EEPROM_Failed	The procedure to write the image of the OBS currently running in PM into the EEPROM, failed	The number of errors occurred during the procedure
0x813	Busy_table	The table for which a creation or update has been requested, is currently in use (by either a VM, or HK sampling or monitoring)	The requested Table ID
0x0815	Illegal_Frame_ID	The Frame_Id number contained in a TC is outside the allowed 00-0F,10-15 or 20-21 ranges	The requested Frame_Id
0x0816	Illegal_Sel_Table_ID	The Table ID number contained in a TC is outside the allowed 0-127 range	The requested Table_ID
0x0817	Undefined_Sel_Table	Table n. Table_ID not defined	Ibidem
0x0818	Invalid_len_Sel_Table	The length of table n. Table_ID doesn't match with selected Frame_ID's length	The tables's length
0x0819	Invalid_content_Sel_Table	The content of table n. Table_ID doesn't contain a valid boolean {0,1} value array for selection	The requested Table_ID
0x0820	Peak_Up_error	(NYI)	(NYI)
0x0821	Illegal_HK_Packet_ID	The HK Packet ID contained in a TC is not in the allowed range 0-3	Uplinked HK Packet ID
0x0822	Illegal_HK_SID	The MSB of the HK SID in a (3,x) TC is not 0x03	Uplinked HK SID
0x0823	Illegal_HK_Table_ID	The Table ID number contained in a TC is outside the allowed 0-127 range	Uplinked Table ID
0x0824	Illegal_HK_Sampling_Interval	The sampling interval contained in a TC is below the minimum allowed threshold (10ms) specified in RD2.	Required sampling interval (in ms)
0x0825	Undefined_HK_Table	A TC was received,	The required

		linking an HK Packet ID to a Table ID which was not previously defined	undefined Table ID
0x0826	Undefined_Monitoring_Table	The Table requested for the HK monitoring in a TC was not previously defined	The required undefined Table ID
0x0827	Err_HK_Sampling_Running	A new TC HK report definition was received while the sampling is still running (i.e, before a TC was sent. The only exception is the case where the only modification requested is the sampling interval.	The HK Packet ID contained in the received TC, and which is still running
0x0828	Illegal_Monitoring_Table	The Table requested for the HK monitoring in a TC is not in the valid 0-127 range.	The required Table ID
0x829	Undefined_HK_ID	The HK packet ID requested in a TC does not correspond to a currently running sampling either defined one	The HK Packet ID contained in the TC, and which is not running
0x0830	Function_Active	The request Function is already activated	Function Enable Status
0x0831	Function_Stopped	The request Function is already stopped	Function Enable Status
0x0E01	Illegal_Type	The Packet Type to be Enabled/Disable not compliant to OBS's ICD	Type
0x0E02	Illegal_SubType	The Packet SubType to be Enabled/Disable not compliant to OBS's ICD	SybType
0x0E03	Illegal_SID	The Packet SID to be Enabled/Disable not compliant to OBS's ICD	SID
0x0E04	Bad_NPCKTS	The number of Packets to be Enabled/Disable don't match with packet length	NPCKTS

Table 6-1 TC Verification Error Codes

7 OBS Objects

7.1 Memory Pools

Due to incorrect Virtuoso's Memory Pools behaviour, DPU Memory Pools is now managed by our internal handling procedures. The memory areas in which memory blocks used to store packets are now statically placed in data memory. Pools IDs are specified as follows:

Pool_ID	Data type
1	TC packets
2	Event TM packets
3	TC verification report TM packets
4	HK TM packets
5	Science Data TM packets

Table 7-1 Memory Pool ID definition

8 Virtuoso Objects

8.1 Memory Pools

Due to incorrect Virtuoso's Memory Pools behaviour, DPU Memory Pools is now managed by our internal handling procedures. The memory areas in which memory blocks used to store packets are now statically placed in data memory. Pools IDs are specified above at § 6.1

8.2 OBS Tasks

The OBS is structured in a series of Virtuoso Tasks (see **Errore. L'origine riferimento non è stata trovata.**). Task IDs are specified as follows:

Task_ID	Task Name
0x0	(Reserved for debugging)
0x1	INIT
0x2	TIME_TASK
0x3	TMTC
0x4	VM_0
0x5	VM_1
0x6	VM_2
0x7	VM_3
0x8	VM_AFX
0x9	HS
0xA	(Reserved for debugging)
0xB	VM_SVC
0xC	LS
0xD	CMD_SEQ
0xE	HK_ASK0
0xF	HK_ASK1
0x10	HK_ASK2
0x11	HK_ASK3
0x12	HK_MON
0x13	ERRAUTO_SEQ
0x14	TABLER
0x15	(Reserved for debugging)

Table 8-1 OBS Task ID definition

8.3 FIFOs

Virtuoso FIFOs are message queues used to exchange information between different OBS Tasks. FIFO IDs are specified as follows:

FIFO_ID	FIFO Name
0x0	TC_HP_QUEUE
0x1	TC_LP_QUEUE
0x2	EV_TM_QUEUE
0x3	HK_TM_QUEUE
0x4	SD_TM_QUEUE
0x5	LS_HP_QUEUE
0x6	LS_LP_QUEUE
0x7	ERR_HP_QUEUE
0x8	ERR_LP_QUEUE
0x9	VM_TM_QUEUE

Table 8-2 Virtuoso FIFO ID definition

9 DPU Memory Map

The OBS organizes the DPU memory as specified in the architecture file **spire.ach**, summarized in the table below:

Memory Type	Start Address	End Address	Segment Description
Program Memory	0x000000	0x0000FF	Used to store the Interrupt Vector Table
	0x000100	0x003FFF	BootUp OBS Loader Program
	0x004000	0x004FFF	Static Variable Initializer Storing Area
	0x005000	0x07FFFF	Used to store the OBS executable at runtime. It is currently sized to the whole PM.
Data Memory	0x00000000	0x0004FFFF	Used for static data allocation, e.g. all variables declared in the OBS routines.
	0x00050000	0x000503FF	Used as stack space for the idle task and interrupt service routines.
	0x00050400	0x0007FFFF	This is the heap. The VIRTUOSO task and fifoes are resident here.

Table 9-1 DPU Memory Map