

Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: i of viii

ROSETTA-NAVCAM

 \mathbf{to}

Planetary Science Archive Interface Control Document

Prepared By:	
	Colin Archibald, Maud Barthelemy
Approved By:	

David Heather



$\begin{array}{c} \text{EAICD} \\ \text{ROSETTA-NAVCAM} \end{array}$

Doc. ID: RO-SGS-IF-0001 Version: 3.1 Page: ii of viii

Table 1: Distribution List.

Recipient	Organisation	Contact
Rosetta SGS	ESA/ESAC	rsgs_dev@sciops.esa.int

Table 2: Document Change Log.

Date of Update	Update to Docu-	New Version	Name
	ment		
2010 Oct 20	Creation of document	V 1.0	Colin Archibald
2012 Jun 26	Corrections	V 2.0	Maud Barthelemy
2013 Jan 08	Corrections;	V 3.0	Bernhard Geiger
	added Sections 2.5,		
	3.2.3, 3.2.4, 3.2.5		
2013 Aug 30	Corrections in Sec-	V 3.1	Bernhard Geiger
	tions 2.6.1, 3.1.2		



$\begin{array}{c} \textbf{EAICD} \\ \textbf{ROSETTA-NAVCAM} \end{array}$

Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: iii of viii

Contents

1	Intr	roduction	1
	1.1	Purpose and Scope	1
	1.2	Archiving Authorities	1
	1.3	Contents	2
	1.4	Intended Readership	2
	1.5	Applicable Documents	2
	1.6	Reference Documents	2
	1.7	Contact Names and Addresses	3
${f 2}$	Ove	erview of Instrument Design, Data Handling Process and Product	
		neration	4
	2.1	Architectures and Configurations	5
		2.1.1 Camera Optical Head (CAM-OH)	5
		2.1.2 Camera Electronic Unit (CAM-EU)	8
		2.1.3 Camera Baffle (CAM-BAF)	9
	2.2	Objectives and Operating Modes	10
		2.2.1 OFF Mode	10
		2.2.2 Initialisation Mode	11
		2.2.3 Stand-by Mode	11
		2.2.4 Imaging Mode	11
		2.2.5 Point Target Tracking Mode	11
		2.2.6 Asteroid (Extended Source) Tracking Mode	12
		2.2.7 Self-Test	13
		2.2.8 Summary of the Operating Modes	13
	2.3	Software for Camera Control	13
	2.4	Data Handling Process	16
	2.5	Telemetry Data	16
	2.6	Overview of Data Products	17
		2.6.1 Expected Releases	17
3	Arc	chive Format and Conventions	.8
	3.1	Format and Conventions	18
		3.1.1 Data Set ID Formation	۱ ی



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: iv of viii

		3.1.2	File Naming Convention	19
	3.2	Standa	ards Used in Data Product Generation	21
		3.2.1	Planetary Data System (PDS) Standards	21
		3.2.2	Time Standards	21
		3.2.3	Camera Reference Frames	22
		3.2.4	Image Orientation	22
		3.2.5	Window Size and Position	23
	3.3	Data (Quality	23
	3.4	Conte	nt	24
		3.4.1	Volume Set	24
		3.4.2	Data Set Naming	25
		3.4.3	Directories	25
4	Det	ailed I	nterface Specifications	29
	4.1	Data l	Product Design	29
		4.1.1	Content of *.LBL Files	29



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: v of viii

List of Tables

1	Distribution List	ii
2	Document Change Log	ii
3	List of contacts for the Navigation Camera (NavCam) instrument archive.	3
4	Overview of NavCam properties	4
5	Summary of NavCam Operating Modes	13
6	NavCam operating modes and state transitions	15
7	Data Processing Levels for the NavCam Data	16
8	Description of Components of the DATA_SET_ID	19
9	Full list of TARGET_ID values for Rosetta	19
10	MISSION_PHASE_NAME and ABBREVIATION	20
11	File naming parameters	20
12	Data quality level and description	23
13	Mandatory keywords and standard values for the VOLUME object	24
14	Data set naming parameters	25
15	Keywords used in NavCam label files	30
16	Rosetta mission specific dictionary entries	32



Doc. ID: RO-SGS-IF-0001 Version: 3.1 Page: vi of viii

List of Acronyms

A/D Analogue-to-Digital

AIU Avionics Interface Unit

AOCMS Attitude and Orbit Control Measurement System

AOCS Attitude and Orbit Control System

APID Application Process Identifier

ASIC Application Specific Integrated Circuit

BIOS Basic Input/Output System

CAM-BAF Camera Baffle

CAM-EU Camera Electronic Unit

CAM-OH Camera Optical Head

CCD Charge Coupled Device

CDS Correlated Double Sampling

CMOS Complimentary Metal Oxide Semiconductor

CODMAC Committee On Data Management, Archiving, and Computation

DDS Data Distribution System

DMS Data Management System

DNA Defocused imaging with No Attenuation

DSP Digital Signal Processing

EAICD Experimenter to (Science) Archive Interface Control Document

ESA European Space Agency

ESAC European Space Astronomy Centre

ESOC European Space Operations Centre



Doc. ID: RO-SGS-IF-0001 Version: 3.1 Page: vii of viii

EU Electronic Unit

FA Focused imaging with Attenuation

FIFO First In / First Out

FNA Focused imaging with No Attenuation

FOV Field of View

ftp file transfer protocol

GSE Ground Support Equipment

HC Health-check

HK Housekeeping

I/F Interface

I/O Input / Output

JPEG Joint Photographic Experts Group

LED Light Emitting Diode

MOS Metal Oxide Semiconductor

MSPS Mobilisation Stationing and Planning System

NASA National Aeronautics and Space Administration

NavCam Navigation Camera

OBT On-Board Time

OH Optical Head

PDS Planetary Data System

PSA Planetary Science Archive

PSA-DH Planetary Science Archive Data Handler

RAM Random Access Memory



Doc. ID: RO-SGS-IF-0001 Version: 3.1 Page: viii of viii

RH reference hole

RL Rosetta Lander

RMOC Rosetta Mission Operations Centre

RO Rosetta Orbiter

ROM Read Only Memory

RSSD Research and Scientific Support Department

S/C Spacecraft

S/W Software

SCIOPS Science Operations Department

SEU Single Event Upset

SSMM Solid State Mass Memory

STR Autonomous Attitude Star Tracker

TC Telecommand

 \mathbf{TM} Telemetry

TTL Transistor-Transistor Logic

UTC Coordinated Universal Time



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 1 of 34

1 Introduction

1.1 Purpose and Scope

This Experimenter to (Science) Archive Interface Control Document (EAICD) has two main purposes. Firstly, it gives users of the Navigation Camera (NavCam) instrument data a detailed description of the product and how it was generated, including data sources and destinations. Secondly, it acts as an interface between the NavCam data producers and the data archiving authority. One point of note is that there are two identical NavCams installed on the Rosetta Spacecraft (S/C), however, for the purposes of this document the singular is generally referred to when discussing the NavCams.

1.2 Archiving Authorities

The Planetary Data System (PDS) standard is used as the archiving standard by:

- the National Aeronautics and Space Administration (NASA) for U.S. Planetary Missions, implemented by PDS;
- the European Space Agency (ESA) for European Planetary Missions, implemented by the Science Operations Department (SCIOPS) of ESA.

ESA implements an on-line science archive, the Planetary Science Archive (PSA), for several reasons:

- to support and ease data ingestion;
- to offer additional services to the scientific user community and science operations teams, such as, e.g.:
 - 1. search queries that allow searches across instruments, missions and scientific disciplines;
 - 2. several data delivery options, such as:
 - direct download of data products, linked files and data sets;
 - file transfer protocol (ftp) download of data products, linked files and data sets.

The PSA aims for on-line ingestion of logical archive volumes and will offer the creation of physical archive volumes on request.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 2 of 34

1.3 Contents

This document describes the data flow of the NavCam instrument on Rosetta from the Spacecraft (S/C) until the insertion into the PSA by ESA. It includes information on how data were processed, formatted, labelled and uniquely identified; along with discussing the general naming schemes for NavCam data volumes, data sets, data and label files. The standards used to generate such products are explained and the design of the data set structure and data products are also given within this document.

1.4 Intended Readership

The staff of the archiving authority (PSA, ESA, Research and Scientific Support Department (RSSD), SCIOPS and operations team) along with any potential user of the NavCam data.

1.5 Applicable Documents

- AD1: Rosetta Archive Generation, Validation and Transfer Plan, January 10, 2006, RO-EST-PL-5011
- AD2: Rosetta Archive Conventions, Mar 25, 2010, RO-EST-TN-3372

1.6 Reference Documents

- RD1: Rosetta Navigation Camera User's Manual, January 2002, RO-GAL-MA-2008
- RD2: Rosetta Navigation Camera Design Description, January 2002, RO-GAL-RP-2007
- RD3: Navigation Camera TM/TC and Software ICD, November 2001, RO-MMT-IF-2007
- RD4: Rosetta SPICE Frame Kernel, ROS_V18.TF



$\begin{array}{c} \textbf{EAICD} \\ \textbf{ROSETTA-NAVCAM} \end{array}$

Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 3 of 34

1.7 Contact Names and Addresses

Table 3: List of contacts for the NavCam instrument archive.

SRE-OO	David Heather	Tel.:
ESAC, P.O. Box, 78,		+34 91 81 31 183
Villanueva de la Cañada,		E-Mail:
28691, Madrid, Spain.		dheather@sciops.esa.int
SRE-OD	Maud Barthelemy	Tel.:
ESAC, P.O. Box, 78,		+34 91 81 31 248
Villanueva de la Cañada,		E-Mail:
28691, Madrid, Spain.		mbarthelemy@sciops.esa.int
SRE-OD	Bernhard Geiger	Tel.:
ESAC, P.O. Box, 78,		+34 91 81 31 169
Villanueva de la Cañada,		E-Mail:
28691, Madrid, Spain.		Bernhard.Geiger@sciops.esa.int
SRE-OD	Michael Küppers	Tel.:
ESAC, P.O. Box, 78,		+34 91 81 31 149
Villanueva de la Cañada,		E-Mail:
28691, Madrid, Spain.		Michael.Kueppers@sciops.esa.int



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 4 of 34

2 Overview of Instrument Design, Data Handling Process and Product Generation

In order to fully satisfy the requirements and objectives regarding navigation and attitude control, Galileo Avionica developed a mission-specific Navigation Camera for Rosetta by building on the heritage of existing models. Table 4 provides an overview of some of the physical and operational parameters of the NavCam.

Table 4: Overview of NavCam properties.

Parameter	Value	Comment
Mass CAM-OH	6.050 kg	
Mass CAM-EU	2.700 kg	
Mass CAM-BAF	1.408 kg	
Total Mass	10.158 kg	
Total Power	16.8 W	
Field of View	$5^{\circ} \times 5^{\circ}$	
Sensor Type	CCD	
Number of Pixels	1024×1024	
Focal Length	152.5 mm	
Pixel Size	$13~\mu\mathrm{m}$	
Pixel Angular Size	17 arcsec	
Aperture	70 mm	Non-Attenuated Modes
	30 mm	Attenuated Mode
F/Number	f/2.2	Non-Attenuated Modes
	f/5.1	Attenuated Mode
Limit Magnitude	$M_v = 11$	Exposure time 5 s, SNR \geq 5
Saturation Magnitude	$M_v = 1.6$	Whole spectral range,
	$M_v = 0.8$	G2 Class; exposure time = 10ms
Integration time	10 ms	Minimum,
	$30 \mathrm{s}$	maximum
Bias error (1σ)	0.2 pixels	$M_v = 11$, exposure time = 5 s,
		Defocused mode
NEA (1σ)	0.1 pixels	$M_v = 11$, exposure time = 5 s,
		Defocused mode
Commanded window size	20×20	Minimum pixel array
	1024×1024	Maximum pixel array
CCD Operative temp.	-50°	Minimum
range	+50°	Maximum
CCD Performance Temp.	-25°	Minimum
Range	0°	Maximum



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 5 of 34

2.1 Architectures and Configurations

The NavCam comprises a Camera Optical Head (CAM-OH), a Camera Electronic Unit (CAM-EU) and a Camera Baffle (CAM-BAF).

2.1.1 CAM-OH

The CAM-OH for the Rosetta NavCam consists of a Charge Coupled Device (CCD) detector and a set of electronics, including:

• PROXIMITY ELECTRONICS:

- 1. CCD drivers;
- 2. CCD bias and phase voltage regulators;
- 3. the analogue signal processor:
 - the pre-amplifier;
 - the amplifier with variable gain; and,
 - the Correlated Double Sampling (CDS) amplifying circuit.
- 4. two multiplexers;
- 5. the Analogue-to-Digital (A/D) converter; and,
- 6. the interfaces for:
 - the temperature transducers; and,
 - the Light Emitting Diodes (LEDs) and photodiodes for the cover / attenuation mechanism control.

• TIMING SEQUENCER and CONTROL LOGIC:

- 1. CCD sequencer and analogue channel control; and,
- 2. data interface.

• DIGITAL SIGNALS and POWER INTERFACES:

- 1. digital lines Interface (I/F);
- 2. command I/F; and,
- 3. data I/F.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 6 of 34

All the logic operations that need to be carried out by the optical head are commanded via the Application Specific Integrated Circuit (ASIC); these include the CCD timing control and digital data and the commanded interfaces of the Optical Head (OH) with the Electronic Unit (EU).

The CAM-OH supports the attenuation / cover mechanism in front of the optics. This includes three exchangeable optical elements in order to make possible the following functions, the second line of each provides the reader with the Rosetta mission specific keyword for ROSETTA:CAM_COVER_POSITION (Summarised in Table 16):

- Defocused imaging with No Attenuation (DNA)
 Specific keyword value DEFOC_NATT;
- Focused imaging with Attenuation (FA)
 Specific keyword value FOC_ATT; and,
- Focused imaging with No Attenuation (FNA)
 Specific keyword value FOC_NATT.

All three positions of the mechanism provide protection to the internal section of the NavCam from debris in the space environment.

Configuration

The CCD enables the NavCam to image objects in the camera Field of View (FOV) and perform the image readout out line-by-line. As the first line of pixels are interrogated and read into the EU each following line is moved pixel-by-pixel to occupy the space of the first line, thus, freeing the row of pixels at the opposing end. By operating in such a manner the NavCam can begin the next image before the first one has completed the read-out process and, hence, reduce the image lag. This can be particularly useful when having to perform a sequence of quickly resolved images, e.g. during navigation for the Rosetta Lander (RL) descent.

The *CCD drivers* translate Transistor-Transistor Logic (TTL) signals, produced via the timing sequencer, to the Metal Oxide Semiconductor (MOS) levels, required by the CCD, to operate correctly over the correct time-scale and drive the relatively high capacitive load presented.

Charge-shifting rates of 2 μ sec are used for the vertical (parallel) transfers, while 250 nsec and 3.6 μ sec rates are used for the non-processed and A/D converted pixels in the horizontal (serial) transfers respectively.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 7 of 34

The *CCD bias and phase voltage regulators* supply the voltage levels to bias the CCD and the levels to which the timing signals must be translated.

The *analogue signal processor* uses two gain levels and again the second line gives the values for the Rosetta mission specific keyword related to this parameter - ROSETTA:CAM_GAIN (Table 16):

- 1. G_high increases the grey signal level resolution when faint targets are imaged Specific keyword value HIGH; and,
- 2. G_low used when bright targets are imaged Specific keyword value LOW.

The *two multiplexers* (8-channel Complimentary Metal Oxide Semiconductor (CMOS) HS-508A chips) are used to acquire the CCD data and all the needed Health-check (HC) signals. The CCD sequencer block of the OH ASIC selects, with a given sequence, the various channels to perform the readout of a given signal. The readout of all HC signals is performed before the readout of the CCD data.

The A/D converter is a high speed monolithic 12-bit, 1.25 Mobilisation Stationing and Planning System (MSPS), with an on-chip sample-and-hold amplifier.

The *CCD sequencer and analogue channel control block* produces CCD timings and (simultaneously) drives a First In / First Out (FIFO) control system for pixel storage and direct interfacing with all processor buses. It is this block that constructs the signals for the following operations:

- CCD clocking; and,
- analogue channel control:
 - clamp;
 - sample;
 - gain switch; and,
 - A/D conversion.

The sequencer opens CCD windows, selects the window gain, and, commands the CCD operations and pixel grouping. Within the OH electronics a separate sub-block is incorporated to, solely, deal with HC signal acquisition and conversion from different sources.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 8 of 34

The sequencer can be completely re-configured by means of an external Read Only Memory (ROM); designed to store all waveforms that drive the CCD and analogue signal controls. Re-loading the external ROM and running a complete waveform sequence via the ASIC occurs at every CCD scan cycle; by doing so the possibility of a Single Event Upset (SEU) is minimized. The logic is completely synchronous and uses a single port for waveform storage in the form of a static Random Access Memory (RAM) chip with a total size of 16 Kbits.

The *data interface* is a small FIFO based serial link, for command outputting and pixel data inputting, general purpose bus interfacing consisting of two sub-blocks:

- Command I/F; and,
- Pixel input I/F.

The command I/F serialises a command stream (written in a small FIFO 32 by 32 processor) and sends it to the CCD sequencer. The pixel input I/F will accept the serial stream originating from the CCD sequencer and write the data in a large FIFO (1 Kb by 24 word) location, ready for reading by a microprocessor.

2.1.2 CAM-EU

The CAM-EU contains: all of the digital electronics, interfaces for data Input / Output (I/O) with the Avionics Interface Unit (AIU) and Solid State Mass Memory (SSMM), and finally, the DC/DC power converter. The ASIC used in the OH for CCD timing is designed to implement, by a dedicated section, the interfaces from the EU in the direction of the OH. Therefore, two identical ASICs are utilised in the NavCam system; one in the OH and one in the EU; to provide interfacing in both directions. The EU sends the control commands required by the OH and processes the digital signals coming from the OH to realise the target detection and tracking capabilities. In general the EU provides overall control of the instrument and comprises three main blocks, including two Digital Signal Processing (DSP) boards:

- the DSP board with NavCam processor and related interfaces;
- the DSP board with Autonomous Attitude Star Tracker (STR) processor and related interfaces; and,
- the power section.



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 9 of 34

Configuration

The common DC/DC converter module provides functioning for: conditioning, switching, conversion and distribution of the power supply from the EU and CAM-OH. It provides a common functionality that implements primary power conditioning functions and separate DC/DC conversions for both the NavCam and STR modules, including both DSPs.

Another major function of this module is to provide the programmable constantcurrent driver for, both, the heater in the OH and the stepper motor that actuates the NavCam attenuation / cover mechanism.

The NavCam **DSP** board controls the processing of the data from the NavCam and incorporates the following modules:

- the DSP itself;
- the memory banks;
- the DSP peripherals;
- the interfacing between the AIU, SSMM and the OH; and,
- the instrument control function, including:
 - the thermal control for the OH; and,
 - the cover / attenuation mechanism position controls.

2.1.3 **CAM-BAF**

The CAM-BAF provides protection against stray light produced by the sun and reflected from the planetary bodies and the satellite. This level of protection allows the tracking of faint objects.

Configuration

The CAM-BAF is mechanically supported by the S/C structure so as to avoid mechanical stress of the OH. This is done due to the required high pointing stability of the CAM-OH to its boresight in order to achieve the desired accuracies from the NavCam.



Doc. ID: RO-SGS-IF-0001 Version: 3.1 Page: 10 of 34

2.2 Objectives and Operating Modes

The Rosetta NavCam does not have any *scientific* objectives, as such, to speak of. Instead, the aims of this instrument are to provide the Rosetta S/C with several capabilities through a series of operating modes. In general the camera has three major functions:

- 1. Point Tracking;
- 2. Asteroid (or Extended Object) Tracking; and,
- 3. Imaging

and, more precisely, seven operational modes:

- OFF Mode;
- Initialisation;
- Stand-by;
- Imaging;
 - INSTRUMENT_MODE_ID = "IMAGING";
- Point-Target Tracking;
- Asteroid (Extended Object) Tracking;
 - INSTRUMENT_MODE_ID = "ASTEROID_TRACKING"; and
- Self Test.

Science data (i.e., images) can only be generated and downlinked to ground in the Imaging and Asteroid (Extended Object) Tracking modes. In the archived data sets, the used mode is indicated by the INSTRUMENT_MODE_ID keyword of the label files as indicated above (also see Table 15).

The following sections give a description of each of the operational modes and the multiple abilities they provide.

2.2.1 OFF Mode

In this mode the camera is dormant and devoid of all power.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 11 of 34

2.2.2 Initialisation Mode

In this mode the NavCam autonomously loads and runs the bootstrap into a devoted section of the RAM at switch-on, activates the interfaces and awaits a Telecommand (TC) from the AIU. The content of all RAM is left unchanged - except that of the RAM location devoted to the initialisation and Software (S/W) maintenance modes - so that it may be fully tested following a specific TC being sent from the AIU. Finally, the switch to stand-by mode (start application S/W) is commanded by the AIU.

2.2.3 Stand-by Mode

In this mode the instrument achieves and maintains the nominal operating conditions, e.g. the CCD operating temperature, in order to rapidly react to the Attitude and Orbit Control Measurement System (AOCMS) commands. While operating in stand-by mode the power consumption is minimised and S/W services can be commanded quickly and easily.

2.2.4 Imaging Mode

Allows the camera to operate as a standard camera, targeting and resolving images of: the star-field in the camera FOV, extended sources such as asteroids, comets or planets in the camera FOV, or, features of the comet 67P/Churyumov-Gerasimenko during the orbits and finally the descent of the RL. This mode can be operated independently or as a sub-mode of the Asteroid (Extended Object) Tracking mode.

2.2.5 Point Target Tracking Mode

The Point Target Tracking mode has several applications when addressing the Rosetta NavCam objectives:

• Autonomous Acquisition of a Star-Field

This will allow the NavCam to, firstly, recognise and then lock a star-field and is accomplished by the collection and processing of images in the entire FOV without *priori* knowledge being gained from the use of other sensors. By operating in this way the NavCam / STR can perform the coarse attitude determination and evaluate manoeuvres that may need to be performed to ensure the correct pointing of the satellite is maintained.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 12 of 34

Following from this operation is the method of Autonomous Star-Tracking.

• Autonomous Tracking of Stars

Autonomous Star-Tracking allows the NavCam to collect images of stars locked in the FOV (or from new stars entering the FOV) and evaluate fine attitude control manoeuvres (pitch, roll and yaw) that may need to be performed.

• Commanded Star-Tracking

Upon being provided with the coordinates, motion rate and magnitude of (up to) five selected stars, the NavCam can autonomously track these within the camera's FOV.

• Provide the AIU with Position and Magnitude measurements

The NavCam shall also be able to provide the AIU with the position and magnitude measurements of the ten brightest objects within the camera FOV. This mode can be used to provide information along with the images of deep-space; so as to allow a comparison against a catalogue of stars for determination of position and pointing direction of the Rosetta S/C.

2.2.6 Asteroid (Extended Source) Tracking Mode

The objectives to be satisfied here are essentially the same as for the autonomous star-field acquisition and tracking modes:

• Autonomous Acquisition of Extended Sources

This will allow the NavCam to, firstly, recognise and then lock an extended source and is accomplished by the collection and processing of images in the entire FOV without *priori* knowledge being gained from the use of other sensors. By operating in this way the NavCam / STR can perform the coarse attitude determination and evaluate manoeuvres that may need to be performed to ensure the correct pointing of the satellite is maintained.

Following from this operation is the method of Autonomous Extended Source Tracking.

• Autonomous Tracking of Extended Sources

Autonomous Extended Source Tracking allows the NavCam to collect images of asteroids, comets or planets locked in the FOV and evaluate fine attitude control manoeuvres (pitch, roll and yaw) that may need to be performed. The secondary outcome of this operational mode allows the instrument to evaluate rates of motion with a specified repetition rate.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 13 of 34

2.2.7 Self-Test

This mode operates by providing, upon request, the health-check Housekeeping (HK)-Telemetry (TM) without destroying the contents of any memory locations.

2.2.8 Summary of the Operating Modes

Table 5 demonstrates a summary of each of the operating modes and provides a brief description of the scope for each.

Table 5: Summary of NavCam Operating Modes.

Mode	Description
OFF Mode	The NavCam is completely off and devoid of power.
Initialisation	Switch-on of NavCam.
Stand-by Minimise power consumption and prepare for S/W command	
Imaging	Produces and transmits a solid image.
Point Target	To recognise, lock and autonomously track a (point like) star-
Tracking	field providing coarse and fine attitude corrections to the
Mode	AOCMS respectively. Provide position and magnitude measure-
	ments to the AIU. Track up to five stars within the FOV of
	given coordinates.
Asteroid	To recognise, lock and autonomously track an extended ob-
(Extended	ject, providing both coarse and fine attitude corrections to the
Object)	AOCMS. Provide position and magnitude measurements to the
Tracking	AIU along with observed rates of motion with a specified repe-
Mode	tition rate.
Self-test	Provide the HK-TM upon request.
(Trouble-	
shooting)	

2.3 Software for Camera Control

The camera software makes it possible to either command the NavCam from the ground or autonomously control it on board the S/C. These commands are first routed by the Data Management System (DMS) TC router then by the Attitude and Orbit Control



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 14 of 34

System (AOCS) TC router to the NavCam based on the Application Process Identifier (APID) value. The on-board instrument S/W consists of the following:

- 1. Application Management S/W:
 - Initialisation S/W; and,
 - Application S/W.
- 2. Basic Input/Output System (BIOS) and Auxiliary Functions:
 - Power-on and initialisation function (Start-up);
 - device drivers (library);
 - EU self-test functions (library);
 - EU overall self-test program (library/function); and,
 - S/W services (library).

In addition to this autonomously commanded S/W there is also a full set of TCs that can be executed by the AOCS. The initialisation S/W is used immediately after power-on (from OFF mode) and is only used during the initialisation mode. While the application S/W can be used in stand-by mode to access another mode state as well as being operated, in some instances, to transfer from one mode state to the next (if applicable). This is summarised in Table 6.

Both the initialisation and application S/W can execute the following operations:

- S/W program control;
- Communication handling;
- S/W maintenance; and,
- Board handling.

While the initialisation S/W can also perform the default readout sequence and the application S/W performs the specific tasks of:

- Housekeeping (HK) (including: thermal control, HC and memory scrubbing);
- On-Board Time (OBT) and OH handling.



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 15 of 34

Table 6:	NavCam	operating	modes	and	state	transitions
Table 0.	Tiav Call	Operaums	modes	and	Duade	or correction to

Mode	Event and Transition From	Event and Transition To
OFF	$\leftarrow All \ Operative \ Modes:$	ightarrow Initialisation:
	OFF command	ON command from RTU
Initialisation	\leftarrow OFF:	ightarrow Initialisation:
	ON command from RTU	after bootstrap completion
		after RAM check completion
		after S/W loading to RAM
	\mid \leftarrow All Operative Modes:	ightarrow Stand-by:
	S/W reset TC	start application S/W TC
Stand-by	\leftarrow Initialisation:	
	start application S/W TC	
	$ig \leftarrow Imaging:$	ightarrow Imaging:
	Stand-by entering command	Image entering command
	$\mid \leftarrow Point \; Target \; Tracking:$	$ ightarrow Point \ Target \ Tracking:$
	stand-by entering command	Point target tracking entering
	all targets lost	command
	$\mid \leftarrow Asteroid \; Tracking:$	$ ightarrow A steroid \ Tracking:$
	Stand-by entering command	Asteroid tracking entering
		command
	$\mid \leftarrow Self\text{-}Test:$	$ ightarrow Self ext{-} Test:$
	Test completion	Self-test entering command
Imaging	\leftarrow $Stand-by:$	ightarrow Stand-by:
	Imaging entering command	Stand-by entering command
	\mid \leftarrow $Imaging:$	ightarrow Imaging:
	Imaging entering command	Imaging entering command
Point Target	\mid \leftarrow $Stand-by:$	ightarrow Stand-by:
Tracking	Point target tracking entering/	Stand-by entering command
	updating command	All targets lost
	$\leftarrow Point \ Target \ Tracking:$	$ ightarrow Point \ Target \ Tracking:$
	Point target tracking entering/	Point target tracking entering/
	updating command	updating command
Asteroid	\leftarrow $Stand-by:$	ightarrow Stand-by:
Tracking	Asteroid tracking entering/	Stand-by entering command
	updating command	
	\leftarrow Asteroid Tracking:	$ ightarrow A steroid \ Tracking:$
	Asteroid tracking entering/	Asteroid tracking entering/
	updating command	updating command
Self-Test	\leftarrow Stand-by:	ightarrow Stand-by:
	Self-test entering command	Self-test completion



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 16 of 34

2.4 Data Handling Process

The NavCam data will be primarily used by the Rosetta Mission Operations Centre (RMOC) team at European Space Operations Centre (ESOC), Germany, where the data will be used to help ensure the S/C's position, pointing and attitude are correct. However, to offer data to the scientific community, products produced under the imaging mode have been collated into relevant data sets. The data products are prepared by Bernhard Geiger and Michael Küppers at the European Space Astronomy Centre (ESAC), Spain. The production of the documentation to accompany and explain these products is carried out by the PSA at ESAC. The data levels (according to both PSA and Committee On Data Management, Archiving, and Computation (CODMAC) definition) considered in this documentation are described in Table 7.

Table 7: Data Processing Levels for the NavCam Data.

PSA	CODMAC	Description
1a	1	The level 1 data that have been separated by instru-
		ment. This is the level which is distributed by the
		DDS.
1b	2	Level 1a data that have been sorted by instrument data
		types and instrument modes. Data are in scientifically
		useful form, e.g. as images. These data are still uncal-
		ibrated.
2	3	Level 1b with calibration and corrections applied to
		yield data in scientific units.
3	5	Higher level data products developed for specific scien-
		tific investigations.

2.5 Telemetry Data

For generating the product files the following telemetry data are processed:

- Science Data Report: TM APID 460 (CAM1) and 476 (CAM2), Type 20, Subtype 13. This set of telemetry data contains the images as well as a number of meta data parameters. The latter are included in the label files of the generated data products.
- Housekeeping and Health-Check Report: TM APID 452 (CAM1) and 468 (CAM2), Type 3, Subtype 25. From the set of available housekeeping parameters only the



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 17 of 34

CCD temperature and the optics temperature are extracted and included in the label files of the generated data products.

2.6 Overview of Data Products

2.6.1 Expected Releases

Due to the inherent nature of the NavCam instrument there will be no reason to produce any CODMAC level 5 data sets and only levels 2 and 3 (see Table 7) will become available for release. The scientific community should expect to have made available to them data products from the Imaging Mode - including images produced while operating under the Asteroid (Extended Object) Tracking mode. These images will include some basic header information. Each released volume will follow the format and structure outlined in Chapter 3. Full explanations of the parameters found in the label files and headers, along with an explanation of the camera readout frame, are provided in Chapter 4.

Uncalibrated Data

Raw data sets are made available, which contain meta-information on the used instrument modes and geometry in the product label files of the images. The data result from multiple mission phases (see Table 10) and include images of star-fields and extended objects: Earth, Mars, Asteroid 21-Lutetia, Asteroid 2867-Steins and Comet 67P/Churyumov-Gerasimenko.

Calibrated Data (Not Yet Available)

From the raw data sets the calibration software will allow for necessary adjustments to be made to the images for the production of the CODMAC level 3 data via a calibration pipeline. The data sets expected for release will be calibrated versions of all the data releases for the raw data sets.



$\begin{array}{c} \text{EAICD} \\ \text{ROSETTA-NAVCAM} \end{array}$

Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 18 of 34

3 Archive Format and Conventions

This chapter contains general rules for the NavCam data sets. The format and convention used for naming directories and files are specified below.

3.1 Format and Conventions

The directory tree must be compatible, in terms of directory organisation and naming and file organisation, with the PDS standards and such that:

- each logical archive volume shall contain <u>one</u> NavCam PDS data set;
- data sets will contain data from both NavCams;
- one data set shall be created for each separate mission phase;
- a different data set shall be created for each processing level;
- the top level directory of each logical archive volume shall match that of the NavCam data set ID; and,
- the volume set name shall be as that of the data set.

3.1.1 Data Set ID Formation

The data set ID formation shall be done according to the following rule:

Each of the components are described, briefly, in Table 8, with a full list of options for TARGET_ID and MISSION_PHASE being given in Tables 9 and 10 respectively. Examples include:

- RO-E-NAVCAM-2-EAR1-V1.0
- RO-A-NAVCAM-2-AST1-V1.0

In some instances it can be viewed that there are several TARGET_ID terms in the DATA_SET_ID naming formation. These terms come together in a list, separated by hyphens, between the <INST_HOST> and <INST> terms in the data set name. Examples include:



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 19 of 34

- RO-A-CAL-NAVCAM-2-AST2-V1.0
- RO-E-X-NAVCAM-2-CR1-V1.0

Table 8: Description of Components of the DATA_SET_ID.

Component	Examples	Description	
INST_HOST	RO	Rosetta Orbiter	
TARGET_ID	D A, C, E, M Asteroid, Comet, Earth, Mars		
INST	NAVCAM Navigation Camera		
CODMAC_LEVEL	2, 3, 5	See Table 7	
MISSION_PHASE_	AST1,	Asteroid 1 Flyby, Earth Swingby 3,	
ABBREVIATION	EAR3,	Cruise 4-B, Mars Swingby	
	CR4B,		
	MARS		
VERSION	Vx.y e.g.	x and y are numerical values indicating	
	V1.0, V1.1,	the version level and revision number	
	V2.0		

Table 9: Full list of TARGET_ID values for Rosetta.

Abbreviation	$TARGET_{-}TYPE$	$TARGET_NAME$
A	Asteroid	(21) Lutetia
		(2867) Steins
С	Comet	C/LINEAR
		9P/TEMPEL 1
		67P/Churyumov-Gerasimenko
CAL	Calibration	
E	Planet	Earth
J	Planet	Jupiter
M	Planet	Mars
N/A	Satellite	Moon
X	N/A	Checkout

3.1.2 File Naming Convention

Each data product found in the /DATA/ directory is presented in the form of a *.IMG file, each of which has an associated *.LBL file of the same name that points to the image



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 20 of 34

Table 10: MISSION_PHASE_NAME and ABBREVIATION.

Phase Name	Abbr.	Phase Name	Abbr.
STEINS FLY-BY	AST1	COMMISSIONING 2	CVP2
LUTETIA FLY-BY	AST2	EARTH SWING-BY 1	EAR1
CRUISE 1	CR1	EARTH SWING-BY 2	EAR2
CRUISE 2	CR2	EARTH SWING-BY 3	EAR3
CRUISE 3	CR3	GROUND	GRND
CRUISE 4-1	CR4A	LAUNCH	LEOP
CRUISE 4-2	CR4B	MARS SWING-BY	MARS
CRUISE 5	CR5	RENDEZVOUS MA-	RVM1
		NOEUVRE 1	
CRUISE 6	CR6	RENDEZVOUS MA-	RVM2
		NOEUVRE 2	
COMMISSIONING 1	CVP1		

file. Each *.LBL file contains the camera operating parameters in the header. Every data product has a browse version in the form of a *.JPG file with an associated *.LBL located in the /BROWSE/ directory. These are provided so as to allow an easier browsing of the data. The naming formation for each *.IMG, *.JPG and *.LBL is as follows:

Table 11 demonstrates the definitions of each part:

Table 11: File naming parameters.

Variable	Possible Values	Description
MISSION	ROS	Demonstrates which mis-
		sion the NavCam is being
		flown on.
CAM#	CAM1, CAM2	Denotes which NavCam
		produced the data.
EXT	IMG, JPG, LBL	Denotes the file type in
		question.

The parameter <YYYYMMDDThhmmss> is the Coordinated Universal Time (UTC) without the fractional seconds (explained in *Standards Used in Data Product Generation: Time Standards*) and provides the date and time at which the image was taken on-board the S/C.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 21 of 34

3.2 Standards Used in Data Product Generation

This section describes the fundamental standards used for the Rosetta NavCam data production.

3.2.1 PDS Standards

Each complete volume produced will be able to pass both the PDS and PSA standards. In general each individual file will be created using standards of the PDS and more specifically Version 3. The PDS format uses the ISO 9660 level 2 standard for the file names. Hence, no complete file name shall be longer than 31 characters and the "27.3" structure will be obeyed, that is, a maximum of 27 characters before the "." for the file name and 3 characters after for the extension type.

3.2.2 Time Standards

Two time standards are used in the production of the NavCam data. Firstly, the standard UTC is used in the time stamping of the data products for the following properties:

- PRODUCT_CREATION_TIME;
- IMAGE_TIME;
- START_TIME; and,
- STOP_TIME

Where the START_TIME = IMAGE_TIME - $0.5 \times \text{EXPOSURE_DURATION}$ and STOP_TIME = IMAGE_TIME + $0.5 \times \text{EXPOSURE_TIME}$. The other time standard is found in the following keywords:

- SPACECRAFT_CLOCK_START_COUNT; and,
- SPACECRAFT_CLOCK_STOP_COUNT.

Where these time standards are defined to be:

- Coordinated Universal Time (UTC):
 - YYYYMMDDThhmmss.fff
 where YYYYMMDD provides the calendar format (year, month and day) of production; T indicates the time at which the event occurred in hhmmss.fff (hours, minutes, seconds and fractions of a second).



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 22 of 34

• SPACECRAFT_CLOCK_START/STOP_COUNT:

- <reset number>/<time counter high value>.<time counter low value><time counter high value> spacecraft clock counts (approximately one second)since initialisation.

<time counter low value> counted in 1/65536 second ticks.

Example:

* 1/123772074.26377

3.2.3 Camera Reference Frames

For data processing and analysis purposes the NavCam reference frames are defined as follows:

- The +Z axis points along the camera boresight (optical axis).
- The +X axis is parallel to the apparent image columns. It is nominally co-aligned with the S/C + X axis.
- The +Y axis completes the right hand frame. It is nominally parallel to the apparent image lines and co-aligned with the S/C +Y axis.
- The origin of the frame is located at the camera focal point.

The actual alignment of the boresights with respect to the spacecraft reference frame as determined by in-flight calibration is given in the Rosetta SPICE frame-kernel [RD4].

3.2.4 Image Orientation

The images in the data product files are oriented such that the CCD columns (and therefore the X axis) appear in vertical direction and the lines (and therefore the Y axis) in horizontal direction. The binary files start with the first byte of the first line read out from the CCD. This first line corresponds to the bottom of the image in the orientation mentioned above. Accordingly, the relevant keywords in the image description section of the product label files are specified as SAMPLE_DISPLAY_DIRECTION = "RIGHT" and LINE_DISPLAY_DIRECTION = "UP".

The orientation of the X and Y axes is such that line and column number counts increase with increasing coordinate value. However, the optics of the instrument introduces an



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 23 of 34

inversion of the image. This means that the signs of both coordinate values need to be reversed when transforming the position of an object in space into image coordinates. Or in other words, the image needs to be rotated by 180 degrees in order to match the orientation of the imaged scene.

3.2.5 Window Size and Position

The camera software allows the user to specify sub-frames in order to reduce the data volume for downlink. In the product label files the size of the images is indicated by the standard keywords LINES and LINE_SAMPLES of the image description section. The specific keywords

ROSETTA:CAM_WINDOW_POS_ALONG_ROW

and

ROSETTA:CAM_WINDOW_POS_ALONG_COL,

respectively, indicate the central column and row numbers of the commanded sub-images (see Table16). For full images with 1024×1024 pixels the value of both of these keywords is set to 511, which corresponds to the centre of the CCD.

3.3 Data Quality

When considering the data quality for the uncalibrated NavCam images there are two levels, as presented in Table 12:

Table 12: Data quality level and description.

DATA_QUALITY_ID	DATA_QUALITY_DESC	Comment
0	COMPLETE	Image Complete
1	INCOMPLETE	Lines Missing

Additional values for this keyword, e.g. indicating image saturation, may be added in later product releases. The number of missing lines can be seen in Table 16 under the Rosetta mission specific keyword ROSETTA:CAM_MISSING_LINES. The keyword ROSETTA:CAM_DATA_VALID with the possible values OK or NOT_OK reports the result of a periodic instrument health check which is included in the science telemetry data. This error flag is set, for example, if the instrument temperature is not within the operating range.



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 24 of 34

3.4 Content

This section contains information that is data product independent and is common to all data sets produced for the Rosetta NavCam.

3.4.1 Volume Set

The following conditions shall remain true for the NavCam data sets at all times:

- Each logical archive volume shall contain one NavCam data set.
- Necessary documentation for the logical archive volumes shall be provided by the Planetary Science Archive Data Handlers (PSA-DHs). Any other non-data file necessary for the logical archive volume will be provided by the PSA-DHs.
- It shall be possible to modify and implement the structure of the directory tree with new sub-directories, whenever needed. The creation and management of the directories shall be performed by the PSA-DHs.

The keywords mandatory for the VOLUME object of the Rosetta mission are presented in Table 13:

Table 13: Mandatory keywords and standard values for the VOLUME object.

Keyword	Required	Max.	Standard Value(s)
		Length	
DATA_SET_ID	yes	40	see Section 3.1.1
DESCRIPTION	yes	N/A	"N/A"
MEDIUM_TYPE	yes	30	"ELECTRONIC"
PUBLICATION_DATE	yes	10	YYYY-MM-DD
VOLUME_FORMAT	yes	20	"ANSI"
VOLUME_ID	yes	12	"N/A"
VOLUME_NAME	yes	60	"N/A"
VOLUME_SERIES_NAME	yes	60	"N/A"
VOLUME_SET_NAME	yes	60	"N/A"
VOLUME_SET_ID	yes	40	"N/A"
VOLUME_VERSION_ID	yes	12	"N/A"
VOLUMES	yes	N/A	"UNK"



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 25 of 34

3.4.2 Data Set Naming

The data set naming for the Rosetta NavCam follows the following formation rule:

DATA_SET_NAME = <INSTRUMENT_HOST_NAME>-<TARGET>(-<OPTIONAL>)-<INST><CODMAC_LEVEL>-<MISSION_PHASE_ABBREVIATION>-<VERSION>

Where each of these parameters are defined in Table 14:

Table 14: Data set naming parameters.

Parameter	Value(s)
INSTRUMENT_HOST_NAME	ROSETTA-ORBITER
TARGET	see Table 9
INST	NAVCAM
CODMAC_LEVEL	see Table 7
MISSION_PHASE_ABBREVIATION	see Table 10
VERSION	e.g. V1.0, V2.4 etc.

Examples include:

- "ROSETTA-ORBITER-EARTH-NAVCAM-2-EAR1-V1.0"
- "ROSETTA-ORBITER-MARS-CALIBRATION-2-MARS-V1.0"

3.4.3 Directories

Root Directory

The top-level structure of the ROOT directory of a data archive volume corresponds to chapter 19 of the PDS Standards Reference (summarised here):

- AAREADME.TXT: This file describes the complete volume. It provides an overview of what can be found in the volume including the organisational attributes and general instructions for use along with contact information.
- VOLDESC.CAT: This file contains the VOLUME object, which gives a high-level description of the volume contents.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 26 of 34

Sub-directories (except the DATA directory) include a file, **xxxxINFO.TXT**, that briefly describes the contents of that directory. In case that an important instrument characteristic cannot be described with an existing PDS keyword, the information will be supplied in a separate parameter file.

BROWSE Directory

This directory contains two directories (CAM1 and CAM2) with a set of thumbnail images in *.JPG format (one corresponding to each *.IMG file in the DATA directory) and an associated *.LBL for each one. Other files that are included here are:

- BROWINFO.TXT: This file describes the contents of the directory.
- *.LBL: Detached label files for the browse products.
- *.JPG: Browse products in JPEG format

CATALOG Directory

This directory contains the catalogue object files for the complete volume. Files include:

- CATINFO.TXT: A description of the contents of the CATALOG directory.
- MISSION.CAT: Contains PDS mission catalogue information about the Rosetta Mission (provided by ESA).
- INSTHOST.CAT: Contains PDS instrument host catalogue information about the Rosetta S/C and the mounting relationship of the instruments within the S/C (provided by ESA).
- NAVCAM_INST.CAT: Contains PDS instrument catalogue information about the instrument (likely to be the same in all deliveries, unless updates are needed).
- **DATASET.CAT**: Contains PDS data set catalogue information about the data set currently being submitted.
- **REF.CAT**: PDS reference catalogue information about every journal article, book or other published reference mentioned in the above catalogue objects or their components.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 27 of 34

- **SOFTWARE.CAT**: PDS software catalogue information about the software submitted in the data set.
- TARGET.CAT: Contains PDS target catalogue information about the observation targets, i.e. comet, asteroid, Earth or Mars (provided by ESA).
- NAVCAM_PERS.CAT: Contains PDS personnel catalogue information about the instrument team responsible for generating the data products.

It should be noted here that the last two files are optional and may not be found in the volume.

DATA Directory

This directory contains two sub directories CAM1 and CAM2 with the data products in the form of *.IMG files each with a corresponding detached *.LBL (label) file.

DOCUMENT Directory

Included here is a copy of all the documentation relative to the data production and the volume as a whole, specific files are:

- **DOCINFO.TXT**: A description of the contents of the document directory.
- RO-SGS-IF-0001.PDF: The Experimenter to (Science) Archive Interface Control Document (EAICD) (this document) for the NavCam instrument.
- RO-SGS-IF-0001.TXT: The ASCII version of the above file.
- RO-SGS-IF-0001.LBL: The label of the above files.

INDEX Directory

Contains index files that summarise all of the data products in the volume by mode, key instrument parameters or mission phase. The files are organised in such a manner to facilitate finding specific data of interest related to a particular *scientific* question. Information about the observation geometry is included in the data products (e.g., spacecraft position and attitude, illumination conditions, etc.). Information that is not accurately known at the time of delivery and thus will probably be updated later shall be stored in the index files rather than in the data product labels. Particular files include:



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 28 of 34

- INDXINFO.TXT: A description of the contents of the directory.
- INDEX.LBL: The detached label file for the file INDEX.TAB. The INDEX_TABLE specific object should be used to identify and describe the columns of the index table.
- INDEX.TAB: Includes the index of the volume in a tabular format.
- BROWSE_INDEX.LBL: The detached label for BROWSE_INDEX.TAB.
- BROWSE_INDEX.TAB: This file includes an index of the browse products in tabular format.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 29 of 34

4 Detailed Interface Specifications

4.1 Data Product Design

According to the PDS formatting standard, each data product must be accompanied by a descriptive *.LBL to describe the content. For the NavCam these label files shall be in the detached form and will appear as a separate file (see Section 3.1.2).

4.1.1 Content of *.LBL Files

The following shall remain true for all label files in all volumes for the Rosetta NavCam:

- The format follows PDS standards for formatting and character usage.
- The labels shall use only valid keywords that appear in both the PDS and PSA dictionaries.
- The character set used shall be that of ASCII 7 bit; specifically characters within and including the code range 001 to 127.
- The characters <CR> and <LF> shall be used and shall be present at the end of each line of every label file.
- Each label file shall not exceed a maximum 80-character limit; including the <CR> <LF> characters.
- Where possible, every line that is less than the permitted 80 character maximum shall be padded out to be of a length equal to 80.

Table 15 provides the list of keywords used in label files within the NavCam volumes; Table 16 signifies Rosetta mission specific dictionary entries.



Doc. ID: RO-SGS-IF-0001 Version: 3.1

Page: 30 of 34

Table 15: Keywords used in NavCam label files.

Keyword	Max.	Value(s)	
	Length		
PDS_VERSION_ID	6	PDS3	
FILE_NAME	N/A	filename	
RECORD_TYPE	20	FIXED_LENGTH	
RECORD_BYTES	N/A	bytes per image line	
FILE_RECORDS	N/A	number of image lines	
INTERCHANGE FORMAT	6	BINARY	
DATA_SET_ID	40	see Section 3.1.1	
DATA_SET_NAME	60	see Section 3.4.2	
PRODUCT_ID	40	filename without extension	
PRODUCT_CREATION_TIME	24	YYYY-MM-DDThh:mm:ss.fff	
PRODUCT_TYPE	30	EDR	
PROCESSING_LEVEL_ID	N/A	"2"	
IMAGE_TIME	24	YYYY-MM-DDThh:mm:ss.fff	
START_TIME	24	YYYY-MM-DDThh:mm:ss.fff	
STOP_TIME	24	YYYY-MM-DDThh:mm:ss.fff	
SPACECRAFT_CLOCK_START	30	see Section 3.2.2	
_COUNT			
SPACECRAFT_CLOCK_STOP	30	see Section 3.2.2	
_COUNT			
MISSION_ID	N/A	ROSETTA	
MISSION_NAME	60	"INTERNATIONAL	
		ROSETTA MISSION"	
INSTRUMENT_HOST_NAME	60	"ROSETTA-ORBITER"	
INSTRUMENT_HOST_ID	6	RO	
TARGET_NAME	30	see Table 9	
TARGET_TYPE	20	see Table 9	
TARGET_DESC	N/A	text description of target	
MISSION_PHASE_NAME	30	see Table 10	



Doc. ID: RO-SGS-IF-0001 Version: 3.1 Page: 31 of 34

PRODUCER_INSTITUTION	60	"EUROPEAN SPACE	
_NAME	00	AGENCY-ESAC"	
PRODUCER_ID	20	"ESA-ESAC"	
PRODUCER_FULL_NAME	60	"BERNHARD GEIGER"	
NOTE	N/A	list of SPICE kernels used	
INSTRUMENT_ID	12	NAVCAM	
INSTRUMENT_NAME	60	"NAVIGATION CAMERA"	
INSTRUMENT_TYPE	30	"CCD CAMERA"	
CHANNEL_ID	4	"CAM1" or "CAM2"	
EXPOSURE_DURATION	N/A	sss.fff <s></s>	
DATA_QUALITY_ID	3	0 or 1	
DATA_QUALITY_DESC	N/A	"0: Image Complete, 1: Lines	
		Missing."	
INSTRUMENT_MODE_ID	20	"IMAGING" or	
		"ASTEROID TRACKING"	
INSTRUMENT_MODE_DESC	N/A	"Value of OPERATING MODE	
		param. in TM data"	
INSTRUMENT_TEMPERATURE	N/A	CCD and optics temperature re-	
		trieved from HK TM	
INSTRUMENT_TEMPERATURE	60	("CCD_T1", "OPTICS_T7")	
POINT			
SUN_POSITION_VECTOR	N/A	spacecraft position in	
	,	ECLIPJ2000 coordinates	
RIGHT_ASCENSION	N/A	right ascension of boresight di-	
	,	rection (J2000)	
DECLINATION	N/A	declination of boresight direc-	
	,	tion (J2000)	
		\ /	



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 32 of 34

Table 16: Rosetta mission specific dictionary entries.

Keyword	Value(s)
ROSETTA:CAM_ABSOLUTE_FRAME_NUMBER	frame number since instru-
	ment start-up
ROSETTA:CAM_MODE_FRAME_NUMBER	frame number in current
	mode
ROSETTA:CAM_COVER_POSITION	FOC_NATT, FOC_ATT, or
	DEFOC_NATT, see p.6
ROSETTA:CAM_GAIN	LOW or HIGH, see p.7
ROSETTA:CAM_DATA_VALID	OK or NOT_OK, see p.23
ROSETTA:CAM_WINDOW_POS_ALONG_ROW	see p.23
ROSETTA:CAM_WINDOW_POS_ALONG_COL	see p.23
ROSETTA:CAM_MISSING_LINES	number of missing image
	lines, see p.23

The following example is that of a label file that can be found for one of the data products:

PDS_VERSION_ID = PDS3

/*** FILE CHARACTERISTICS ***/

FILE_NAME = "ROS_CAM1_20040926T073116.LBL"

RECORD_TYPE = FIXED_LENGTH

RECORD_BYTES = 2048 FILE_RECORDS = 1024 INTERCHANGE_FORMAT = BINARY

/*** POINTERS TO DATA OBJECTS ***/

^IMAGE = ("ROS_CAM1_20040926T073116.IMG",1)

/*** IDENTIFICATION DATA ELEMENTS ***/

DATA_SET_ID = "RO-CAL-NAVCAM-2-CVP2-V1.0"

DATA_SET_NAME = "ROSETTA-ORBITER-CAL-NAVCAM-2-CVP2-V1.0"

PRODUCT_ID = "ROS_CAM1_20040926T073116"

PRODUCT_CREATION_TIME = 2013-05-20T12:40:46

PRODUCT_TYPE = EDR PROCESSING_LEVEL_ID = "2"



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 33 of 34

SPACECRAFT_CLOCK_START_COUNT = "1/54804659.34474"
SPACECRAFT_CLOCK_STOP_COUNT = "1/54804659.35129"

MISSION_ID = "ROSETTA"

MISSION_NAME = "INTERNATIONAL ROSETTA MISSION"

INSTRUMENT_HOST_NAME = "ROSETTA-ORBITER"

INSTRUMENT_HOST_ID = RO

TARGET_NAME = "CALIBRATION"

TARGET_TYPE = "CALIBRATION"

TARGET_DESC = "ALPHA GRU"

MISSION_PHASE_NAME = "COMMISSIONING 2"

PRODUCER_INSTITUTION_NAME = "EUROPEAN SPACE AGENCY-ESAC"

PRODUCER_ID = "ESA-ESAC"

PRODUCER_FULL_NAME = "BERNHARD GEIGER"

NOTE = "SPICE KERNELS USED:

NAIF0009.TLS

ROS_100903_STEP.TSC

ORHR_____00109.BSP

ROS_V16.TF

ATNR_P040302093352_00109.BC"

/*** INSTRUMENT RELATED PARAMETERS ***/

INSTRUMENT_ID = NAVCAM

INSTRUMENT_NAME = "NAVIGATION CAMERA"

INSTRUMENT_TYPE = "CCD CAMERA"

CHANNEL_ID = "CAM1" EXPOSURE_DURATION = 0.01 <s>

DATA_QUALITY_ID = "O"

DATA_QUALITY_DESC = "0: Image Complete, 1: Lines Missing."

INSTRUMENT_TEMPERATURE = (-12.57 <degC>, 8.66 <degC>)
INSTRUMENT_TEMPERATURE_POINT = ("CCD_T1", "OPTICS_T7")



Doc. ID: RO-SGS-IF-0001

Version: 3.1 Page: 34 of 34

/*** ROSETTA MISSION SPECIFIC DATA DICTIONARY ENTRIES ***/ ROSETTA: CAM_ABSOLUTE_FRAME_NUMBER = 9420ROSETTA: CAM_MODE_FRAME_NUMBER = 8935 ROSETTA: CAM_COVER_POSITION = FOC_NATT ROSETTA: CAM_GAIN = LOW ROSETTA: CAM_DATA_VALID = OK ROSETTA: CAM_WINDOW_POS_ALONG_ROW = 511 ROSETTA: CAM_WINDOW_POS_ALONG_COL = 511 ROSETTA: CAM_MISSING_LINES = 0 /*** SPACECRAFT POSITION (ECLIPJ2000) AND INSTRUMENT POINTING (J2000) ***/ SC_SUN_POSITION_VECTOR = (138352393.70 <km>, 80450030.08 <km>, -833729.07 <km>) RIGHT_ASCENSION = 22.117464 <h> DECLINATION = -46.593084 < deg >/*** IMAGE DESCRIPTION ***/ = IMAGE OBJECT DERIVED_MAXIMUM = 968 DERIVED_MINIMUM = 174 LINES = 1024 LINE_SAMPLES = 1024 SAMPLE_TYPE = LSB_UNSIGNED_INTEGER SAMPLE_BITS = 16 SOURCE_SAMPLE_BITS = 12 SAMPLE_DISPLAY_DIRECTION = "RIGHT" = "UP" LINE_DISPLAY_DIRECTION

END

END_OBJECT

= IMAGE